


» Kontron User's Guide «



KTQ67/Flex-Medical Users Guide

KTD-N0849-E

Document revision history.

Revision	Date	By	Comment
E	04/2016	GSZ	New memory SKU
D	Jan. 19 th 2015	MLA	Correction of MIC2 and Line2 location. EXT_BAT max. 3.47V. Chapter 7.22 Riser card note corrected.
C	Jan. 8 th 2014	MLA	Added BIOS features: Force Boot Setup and PC Speaker/Beep.
B	Dec. 13 th 2013	MLA	Revision merged KTD-N00829-E KTQ67 Users Guide.
A	Aug. 22 nd 2013	MLA	First release
0	Aug. 26 th 2011	MLA	Preliminary version

Copyright Notice:

Copyright © 2011, KONTRON Technology A/S, ALL RIGHTS RESERVED.

No part of this document may be reproduced or transmitted in any form or by any means, electronically or mechanically, for any purpose, without the express written permission of KONTRON Technology A/S.

Trademark Acknowledgement:

Brand and product names are trademarks or registered trademarks of their respective owners.

Disclaimer:

KONTRON Technology A/S reserves the right to make changes, without notice, to any product, including circuits and/or software described or contained in this manual in order to improve design and/or performance.

Specifications listed in this manual are subject to change without notice. KONTRON Technology assumes no responsibility or liability for the use of the described product(s), conveys no license or title under any patent, copyright, or mask work rights to these products, and makes no representations or warranties that these products are free from patent, copyright, or mask work right infringement, unless otherwise specified. Applications that are described in this manual are for illustration purposes only. KONTRON Technology A/S makes no representation or warranty that such application will be suitable for the specified use without further testing or modification.

Life Support Policy

KONTRON Technology's PRODUCTS ARE NOT FOR USE AS CRITICAL COMPONENTS IN LIFE SUPPORT DEVICES OR SYSTEMS WITHOUT EXPRESS WRITTEN APPROVAL OF THE GENERAL MANAGER OF KONTRON Technology A/S.

As used herein:

Life support devices or systems are devices or systems which, (a) are intended for surgical implant into body, or (b) support or sustain life and whose failure to perform, when properly used in accordance with instructions for use provided in the labelling, can be reasonably expected to result in significant injury to the user.

A critical component is any component of a life support device or system whose failure to perform can be reasonably expected to cause the failure of the life support device or system, or to affect its safety or effectiveness.

KONTRON Technology Technical Support & Services

If you have questions about installing or using your KONTRON Technology Product, check this User's Manual first – you will find answers to most questions here. To obtain support, please contact your local Distributor or Field Application Engineer (FAE).

Before Contacting Support: Please be prepared to provide as much information as possible:

- CPU Board
 1. Type.
 2. Part Number (find PN on label)
 3. Serial Number if available (find SN on label)
- Configuration
 1. CPU Type, Clock speed
 2. DRAM Type and Size.
 3. BIOS Revision (Find the Version Info in the BIOS Setup).
 4. BIOS Settings different than *Default* Settings (Refer to the BIOS Setup Section).
- System
 1. O/S Make and Version.
 2. Driver Version numbers (Graphics, Network, and Audio).
 3. Attached Hardware: Harddisks, CD-rom, LCD Panels etc.

Warranty

KONTRON Technology warrants its products to be free from defects in material and workmanship during the warranty period. If a product proves to be defective in material or workmanship during the warranty period, KONTRON Technology will, at its sole option, repair or replace the product with a similar product.

Replacement Product or parts may include remanufactured or refurbished parts or components.

The warranty does not cover:

1. Damage, deterioration or malfunction resulting from:
 - A. Accident, misuse, neglect, fire, water, lightning, or other acts of nature, unauthorized product modification, or failure to follow instructions supplied with the product.
 - B. Repair or attempted repair by anyone not authorized by KONTRON Technology.
 - C. Causes external to the product, such as electric power fluctuations or failure.
 - D. Normal wear and tear.
 - E. Any other causes which does not relate to a product defect.
2. Removal, installation, and set-up service charges.

Exclusion of damages:

KONTRON TECHNOLOGY LIABILITY IS LIMITED TO THE COST OF REPAIR OR REPLACEMENT OF THE PRODUCT. KONTRON TECHNOLOGY SHALL NOT BE LIABLE FOR:

1. DAMAGE TO OTHER PROPERTY CAUSED BY ANY DEFECTS IN THE PRODUCT, DAMAGES BASED UPON INCONVENIENCE, LOSS OF USE OF THE PRODUCT, LOSS OF TIME, LOSS OF PROFITS, LOSS OF BUSINESS OPPORTUNITY, LOSS OF GOODWILL, INTERFERENCE WITH BUSINESS RELATIONSHIPS, OR OTHER COMMERCIAL LOSS, EVEN IF ADVISED OF THEIR POSSIBILITY OF SUCH DAMAGES.
2. ANY OTHER DAMAGES, WHETHER INCIDENTAL, CONSEQUENTIAL OR OTHERWISE.
3. ANY CLAIM AGAINST THE CUSTOMER BY ANY OTHER PARTY.

Contents

Introduction	7
1 Installation procedure	8
1.1 Installing the board	8
1.2 Requirement according to IEC60950	9
2 System Specification	10
2.1 Component main data	10
2.2 System overview	14
2.3 Processor Support Table	16
2.4 System Memory support.....	19
2.5 KTQ67 Graphics Subsystem.....	19
2.5.1 Intel® HD Graphics 3000 (example)	20
2.6 Power Consumption	21
3 Connector Locations	24
3.1 KTQ67/Flex-Medical – frontside.....	24
4 Connector Definitions	26
5 IO-Area Connectors	27
5.1 Display connectors (IO Area).....	27
5.1.1 DVI (lower) connector – DVI-I	27
5.1.2 DVI-D (upper) connector – DVI-D.....	28
5.2 Ethernet Connectors (IO Area)	29
5.3 USB Connectors (IO Area)	30
5.3.1 USB Connector 0/1/2/3 (USB0/1/2/3).....	30
5.4 COM1 and COM2 Connectors (IO Area)	31
6 Internal Connectors	32
6.1 Power Connector (ATX/BTXPWR)	32
6.2 Fan Connectors (FAN_CPU) (J28) and (FAN_SYS) (J29)	33
6.3 PS/2 Keyboard and Mouse connector (KBDMSE) (J15).....	34

6.4	Display connectors (Internal).....	35
6.4.1	LVDS Flat Panel Connector (LVDS) (J39) (optionally).....	35
6.5	SATA (Serial ATA) Disk interface (J22 – J27)	36
6.6	USB Connectors (USB).....	37
6.6.1	USB Connector 6/7	37
6.6.2	USB Connector 8/9 (USB8/9) (J18).....	37
6.6.3	USB Connector 10/11 (USB10/11) (J17).....	38
6.6.4	USB Connector 12/13 (USB12/13) (J16).....	38
6.7	Serial COM3 – COM4 Ports (J20, J21).....	39
6.8	Audio Connector	40
6.8.1	Line2 and Mic2	40
6.8.1	Audio Header Connector (AUDIO_HEAD) (J47)	40
6.9	Power Button Connector (PWRBTN) (J48)	41
6.10	Front Panel Connector (FRONTPNL) (J36)	42
6.11	Feature Connector (FEATURE) (J30)	43
6.12	“Load Default BIOS Settings” Jumper (J11)	45
6.13	ClrRTC (J12)	45
6.14	SPI Recover Jumper (J41).....	46
6.15	SPI Connector (SPI) (J40).....	47
6.16	XDP-CPU (Debug Port for CPU) (J14)	48
6.17	XDP-PCH (Debug Port for Chipset) (J13)	49
7	Slot Connectors (PCIe, PCI)	50
7.1	PCIe Connectors.....	50
7.1.1	PCI-Express x16 Connector (PCIe x16).....	50
7.1.3	PCI-Express x4 Connector (PCIe x4) (J33)	52
7.2	PCI Slot Connectors	53
7.2.1	Signal Description – PCI Slot Connector	54
7.2.2	KTQ67 PCI IRQ & INT routing	55
8	On-board - & mating connector types.....	56
9	System Resources.....	57
9.1	Memory Map.....	57
9.2	PCI Devices	58
9.3	Interrupt Usage.....	59
9.4	IO Map.....	60

10	BIOS	61
10.1	Main	61
10.2	Advanced	62
10.2.1	Advanced - PCI Subsystem Settings	63
10.2.2	Advanced - APCI Settings	68
10.2.3	Advanced - Trusted Computing	69
10.2.4	Advanced - CPU Configuration	70
10.2.5	Advanced - SATA Configuration	72
10.2.6	Advanced - Intel® Rapid Start Technology	76
10.2.7	Advanced - Intel TXT (LT) Configuration	77
10.2.8	Advanced - Intel® Anti-Theft Technology Configuration	78
10.2.9	Advanced - AMT Configuration	79
10.2.10	Advanced - Acoustic Management Configuration	81
10.2.11	Advanced - USB Configuration	82
10.2.12	Advanced - SMART Settings	83
10.2.13	Advanced - Super IO Configuration	84
10.2.14	Advanced - Voltage Monitor	89
10.2.15	Advanced - Hardware Health Configuration	90
10.2.16	Advanced - LAN Configuration	92
10.2.17	Advanced - Delay Startup	94
10.2.18	Advanced - Serial Port Console Redirection	95
10.2.19	Advanced - CPU PPM Configuration	99
10.3	Chipset	100
10.3.1	PCH-I/O Configuration	101
10.3.2	System Agent (SA) Configuration	106
10.4	Boot	120
10.4.1	CSM16 parameters	122
10.4.2	Force Boot Setup	123
10.4.3	CSM parameters	124
10.5	Security	125
10.5.1	HDD Security Configuration	126
10.6	Save & Exit	127
11	AMI BIOS Beep Codes	128
12	OS Setup	129

Introduction

This manual describes the KTQ67/Flex-Medical made by KONTRON Technology A/S. In this manual the board will also be denoted KTQ67.

The KTQ67/Flex-Medial is based on the Q67 chipset, support 2nd and 3rd generation Intel® i7 -, i5 -, i3 2Core and 4Core processor and the Celeron B810 2Core, see "Processor Support Table for more specific details.

Use of this Users Guide implies a basic knowledge of PC-AT hard- and software. This manual is focused on describing the KTQ67 board special features and is not intended to be a standard PC-AT textbook.

New users are recommended to study the short installation procedure stated in the following chapter before switching-on the power.

All configuration and setup of the CPU board is either done automatically or manually by the user via the BIOS setup menus. Only exception is the "Load Default BIOS Settings" Jumper.

1 Installation procedure

1.1 Installing the board

To get the board running, follow these steps. If the board shipped from KONTRON has already components like DRAM, CPU and cooler mounted, then relevant steps below, can be skipped.

1. Turn off the PSU (Power Supply Unit)



Warning: Turn off PSU (Power Supply Unit) completely (no mains power connected to the PSU) or leave the Power Connectors unconnected while configuring the board. Otherwise components (DRAM, LAN cards etc.) might get damaged. Make sure PSU has 3.3V monitoring watchdog (standard ATX PSU feature), running the board without 3.3V will damage the board within minutes.

2. Insert the DRAM(s) (UDIMM 240pin)

Be careful to push it in the slot(s) before locking the tabs. For a list of approved DRAM contact your Distributor or FAE. See also chapter "System Memory Support".

3. Install the processor

The CPU is keyed and will only mount in the CPU socket in one way. Use finger to open/ close the CPU socket. Refer to supported processor overview for details.

4. Cooler Installation

Use heat paste or adhesive pads between CPU and cooler and connect the Fan electrically to the FAN_CPU connector.

5. Connecting Interfaces

Insert all external cables for hard disk, keyboard etc. A monitor must be connected in order to be able change BIOS settings.

6. Connect and turn on PSU

Connect PSU to the board by the ATX/BTXPWR and the 4-pin ATX+12V connectors.

7. Power Button

The PWRBTN_IN must be toggled to start the Power supply; this is done by shorting pins 16 (PWRBTN_IN) and pin 18 (GND) on the FRONTPNL connector (see Connector description). A "normally open" switch can be connected via the FRONTPNL connector.

8. BIOS Setup

Enter the BIOS setup by pressing the key during boot up.

Enter Exit Menu and Load Optimal Defaults.

Refer to the "BIOS Configuration / Setup" section of this manual for details on BIOS setup.

Note: To clear all BIOS settings, including Password protection, activate "Load Default BIOS Settings" Jumper for ~10 sec (without power connected).

9. Mounting the board to chassis



Warning: When mounting the board to chassis etc. please notice that the board contains components on both sides of the PCB which can easily be damaged if board is handled without reasonable care. A damaged component can result in malfunction or no function at all.

When fixing the Motherboard on a chassis it is recommended using screws with integrated washer and having diameter of ~7mm.

Note: Do not use washers with teeth, as they can damage the PCB and may cause short circuits.

1.2 Requirement according to IEC60950

Users of KTQ67 should take care when designing chassis interface connectors in order to fulfil the IEC60950 standard:

When an interface/connector has a VCC (or other power) pin, which is directly connected to a power plane like the VCC plane:

To protect the external power lines of the peripheral devices, the customer has to take care about:

- That the wires have suitable rating to withstand the maximum available power.
- That the enclosure of the peripheral device fulfils the fire protecting requirements of IEC60950.

Lithium Battery precautions:

<p style="text-align: center;">CAUTION!</p> <p>Danger of explosion if battery is incorrectly replaced.</p> <p>Replace only with same or equivalent type recommended by manufacturer. Dispose of used batteries according to the manufacturer's instructions.</p>	<p style="text-align: center;">VORSICHT!</p> <p>Explosionsgefahr bei unsachgemäßem Austausch der Batterie.</p> <p>Ersatz nur durch den selben oder einen vom Hersteller empfohlenen gleichwertigen Typ. Entsorgung gebrauchter Batterien nach Angaben des Herstellers.</p>
<p style="text-align: center;">ADVARSEL!</p> <p>Lithiumbatteri – Explosionsfare ved fejlagtig håndtering. Udskiftning må kun ske med batteri af samme fabrikat og type. Levér det brugte batteri tilbage til leverandøren.</p>	<p style="text-align: center;">ADVARSEL</p> <p>Ekspløsjonsfare ved feilaktig skifte av batteri. Benytt samme batteritype eller en tilsvarende type anbefalt av apparatfabrikanten. Brukte batterier kasseres i henhold til fabrikantens instruksjoner.</p>
<p style="text-align: center;">VARNING</p> <p>Explosionsfara vid felaktigt batteribyte. Använd samma batterityp eller en ekvivalent typ som rekommenderas av apparattillverkaren. Kassera använt batteri enligt fabrikantens instruktion.</p>	<p style="text-align: center;">VAROITUS</p> <p>Paristo voi räjähtää, jos se on virheellisesti asennettu. Vaihda paristo ainoastaan laltevalmistajan suosittellemaan tyyppiin. Hävitä käytetty paristo valmistajan ohjeiden mukaisesti.</p>

2 System Specification

2.1 Component main data

The table below summarizes the features of the KTQ67/Flex –Medical embedded motherboard.

Form factor	KTQ67/Flex-Medical: Flex-ATX (190,5 mm by 228,6 mm)
Processor	Support the following Intel® Core™ processors via Socket H2 (LGA1155), ZIF Socket <ul style="list-style-type: none"> • Intel® Core™ i7, 2nd and 3rd Generation • Intel® Core™ i5, 2nd and 3rd Generation • Intel® Core™ i3, 2nd and 3rd Generation • Intel® Pentium® Desktop • 1066/1333MHz system bus and 3/6/8MB internal cache. (Intel® Pentium® Desktop G622 only 1066MHz) • Up to 95W (Thermal Guideline)
Memory	<ul style="list-style-type: none"> • 4x DDR3 UDIMM 240pin socket • Support single and dual ranks DDR3 1066/1333MT/s (PC3-8500/PC3-10600) • Support system memory from 256MB and up to 4x 8GB Note: Less than 4GB displayed in System Properties using 32bit OS (Shared Video Memory/PCI resources is subtracted) • ECC not supported (chipset limitation)
Chipset	Intel Q67 PCH (Platform Controller Hub) <ul style="list-style-type: none"> • Intel® VT-d (Virtualisation Technology for Directed I/O) • Intel® TXT (Trusted Execution Technology) • Intel® vPRO • Intel® AMT (Active Management Technology) version 8 • Intel® AT (Anti-Theft Technology) • Intel® HD Audio Technology • Intel® RST (Rapid Storage Technology) • Intel® RRT (Rapid Recover Technology) • SATA (Serial ATA) 6Gb/s and 3Gb/s. • USB revision 2.0 • PCI Express revision 2.0 • ACPI 3.0b compliant • Dual Display support (Dual Graphic Pipes) • Blue-ray HD video playback
Security	<ul style="list-style-type: none"> • Intel® Integrated TPM 1.2 support
Management	<ul style="list-style-type: none"> • Intel® Active Management Technology (Intel® AMT) 8.0
Audio	Audio, 7.1 Channel High Definition Audio Codec using the VIA 1708B codec <ul style="list-style-type: none"> • Line-out • Line-in • Surround output: SIDE, LFE, CEN, BACK and FRONT • Microphone: MIC1 and MIC2 • CDROM in • SPDIF (electrical Interface only) • On-board speaker (Electromagnetic Sound Generator like Hycom HY-05LF)


Video	<p>Intel ® HD Graphics 4000 or Intel ® HD Graphics 3000 or Intel ® HD Graphics 2500 or Intel ® HD Graphics 2000 or Intel ® HD Graphics, depending on actual CPU.</p> <p>Analogue VGA and digital display ports via the Mobile Intel ® Q67 Chipset.</p> <ul style="list-style-type: none"> • DVI-I & DVI-D ports via Mobile Intel ® Q67 Chipset. (Digital single channel only). • LVDS panel support (optional) up to 24 bit, 2 pixels/clock and 1920x1200. • Dual independent pipes for Mirror and Dual independent display support
I/O Control	Via ITE IT8516E Embedded Controller and Winbond W83627DHG I/O Controller (both via LPC Bus interface)
Peripheral interfaces	<ul style="list-style-type: none"> • Six USB 2.0 ports on I/O area • Eight USB 2.0 ports on internal pinrows • Four Serial ports (RS232) on internal pinrows • Two Serial ATA-600 IDE interfaces (blue) • Four Serial ATA-300 IDE interfaces (black) • RAID 0/1/5/10 support • mSATA via mSATA connector • PS/2 keyboard and mouse ports via pinrow
LAN Support	<ul style="list-style-type: none"> • 1x 10/100/1000Mbps/s LAN (ETHER1) using Intel® Lewisville 82579LM Gigabit PHY connected to Q67 supporting AMT 8.0. Galvanic Isolated. • 1x 10/100/1000Mbps/s LAN (ETHER2) using Intel® Hartwell 82574L PCI Express controller. Galvanic Isolated. • PXE Netboot supported. • Wake On LAN (WOL) supported
Expansion Capabilities	<ul style="list-style-type: none"> • PCI Bus routed to 2x PCI slots (PCI Local Bus Specification Revision 3.0, 33MHz) • PCI-Express slot(s) (PCIe 2.0): • 1 slot PCIe x16 • 1 slot PCIe x4 (in a x16 slot) • SMBus, compatible with ACCES BUS and I2C BUS, (via Feature connector) • SPI bus routed to SPI connector • DDC Bus routed to DP connector when DP Adapters are connected • 5 x digital input, (via Feature connector) • 13 x GPIOs (General Purpose I/Os), (via Feature connector) • DAC, ADC, PWM and TIMER (Multiplexed), (via Feature connector) • WAKE UP / Interrupt Inputs (Multiplexed), (via Feature connector) • 3 Wire Bus for GPIO Expansion (up to 152 GPIOs), (via Feature connector) • 8 bit Timer output, (via Feature connector)

Hardware Monitor Subsystem	<ul style="list-style-type: none"> • Smart Fan control system, support Thermal® and Speed® cruise for FAN_CPU • CPU die temperature input (Precision +/- 3°C) • Voltage monitoring • Intrusion (Case Open) detect input, (via Feature connector) • Sleep S4/S5# Indication, (via Feature connector) • System Powergood Signal, (via Feature connector)
Power Supply Unit	ATX/BTX (w. ATX+12V) PSU for full PCI/PCIe load.
Battery	<p>Exchangeable 3.0V Lithium battery for on-board Real Time Clock and CMOS RAM. Manufacturer Panasonic / Part-number CR-2032L/BN, CR2032N/BN or CR-2032L/BE. Approximate 5 years retention.</p> <p>Current draw is 5,7µA when PSU is disconnected and 0 µA in S0 – S5.</p> <p>CAUTION: Danger of explosion if the battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer’s instructions.</p>
BIOS	<ul style="list-style-type: none"> • Kontron Technology / AMI BIOS (EFI core version) • Support for ACPI 3.0 (Advanced Configuration and Power Interface), Plug & Play <ul style="list-style-type: none"> ○ Suspend (S1 mode) ○ Suspend To Ram (S3 mode) ○ Suspend To Disk (S4 mode) • “Always On” BIOS power setting • RAID Support (RAID modes 0,1, 5 and 10)
Operating Systems Support	<ul style="list-style-type: none"> • WinXP (32b *) • Windows 7 (32b + 64b *) • WES7 (32b * + 64b *) • Linux Fedora * • Linux Ubuntu * • VxWorks (not ready yet) <p>*= Out Of The Box installation test only</p>

Environmental Conditions	<p>Operating: 0°C – 60°C operating temperature (forced cooling). It is the customer's responsibility to provide sufficient airflow around each of the components to keep them within allowed temperature range.</p> <p>10% - 90% relative humidity (non-condensing)</p> <p>Operating altitude: up to 2000 meters</p> <p>Storage: -20°C – 70°C; lower limit of storage temperature is defined by specification restriction of on-board CR2032 battery. Board with battery has been verified for storage temperature down to -40°C by Kontron.</p> <p>5% - 95% relative humidity (non-condensing)</p> <p>Electro Static Discharge (ESD) / Radiated Emissions (EMI): (Pending) All Peripheral interfaces intended for connection to external equipment are ESD/EMI protected. EN 61000-4-2:2000 ESD Immunity EN55022:1998 class B Generic Emission Standard.</p> <p>Safety: IEC 60950-1: 2005, 2nd Edition UL 60950-1 CSA C22.2 No. 60950-1 Product Category: Information Technology Equipment Including Electrical Business Equipment Product Category CCN: NWGQ2, NWGQ8 File number: E194252</p> <p>Theoretical MTBF: 211.994 / 100.475 hours @ 40°C / 60°C for the KTQ67/Flex</p> <p>Restriction of Hazardous Substances (RoHS): The KTQ67 is RoHS compliant.</p> <p>Capacitor utilization: No Tantalum capacitors on board Only Japanese brand Solid capacitors rated for 100 °C used on board</p>
---------------------------------	--

2.2 System overview

The block diagram below shows the architecture and main components of the KTQ67. The key component on the board is the Intel® Q67 (Cougar Point) Mobile Express Chipset.




¹ 2nd generation Intel® Core™ processor family

² Available with Intel processor graphics only

³ All SATA ports capable of 3 Gb/s. 2 ports capable of 6 Gb/s.

⁴ Requires 2nd generation Intel® Core™ vPro processor

More detailed block diagram on next page.



2.3 Processor Support Table

The KTQ67 is designed to support the following LGA1155 processors (up to 95W power consumption):

2nd and 3rd generation Intel® Core™ i7 processor

2nd and 3rd generation Intel® Core™ i5 processor

2nd and 3rd generation Intel® Core™ i3 processor

Pentium and Celeron



In the following list you will find all CPU's supported by the chipset in according to Intel. Please notice that Bus speed 1600 MHz has not been verified yet.

Embedded CPU's are indicated by **green** text, successfully tested CPU's are indicated by **highlighted** text, successfully tested embedded CPU's are indicated by **green and highlighted** text and failed CPU's are indicated by **red** text.

Some processors in the list are distributed from Kontron, those CPU's are marked by an * (asterisk). However please notice that this marking is only guide line and maybe not fully updated.

Processor Brand	Clock [GHz]	Turbo [GHz]	Cores / Threads	Bus [MHz]	Cache [MB]	CPU Number	sSpec no.	Step	TG [W/°C]	Note
17 3 rd Gen. (Ivy Bridge)	3.5	3.9	4 / 8	1333/1600	8	3770K	SR0PL	E1	77/67.4	HDG4000
	3.4	3.9	4 / 8	1333/1600	8	3770	SR0PK	E1	77/67.4	HDG4000
	3.1	3.9	4 / 8	1333/1600	8	3770S	SR0PN	E1	65/69.1	HDG4000
	2.5	3.7	4 / 8	1333/1600	8	3770T	SR0PQ	E1	45/69.8	HDG4000
17 2 nd Gen. (Sandy Bridge)	3.5	3.9	4 / 8	1066/1333	8	2700K	SR0DG	D2	95/72.6	HDG3000
	3.4	3.8	4 / 8	1066/1333	8	2600	SR00B	D2	95/72.6	HDG2000
	3.4	3.8	4 / 8	1066/1333	8	2600K	SR00C	D2	95/72.6	HDG3000
	2.8	3.8	4 / 8	1066/1333	8	2600S	SR00E	D2	65/69.1	HDG2000
15 3 rd Gen. (Ivy Bridge)	3.4	3.8	4 / 4	1333/1600	6	3570	SR0T7	N0	77/67.4	HDG2500
	3.4	3.8	4 / 4	1333/1600	6	3570K	SR0PM	E1	77/67.4	HDG4000
	3.3	3.7	4 / 4	1333/1600	6	3550	SR0P0	E1	77/67.4	HDG2500
	3.2	3.6	4 / 4	1333/1600	6	3470	SR0T8	N0	77/67.4	HDG2500
	3.1	3.8	4 / 4	1333/1600	6	3570S	SR0T9	N0	65/69.1	HDG2500
	3.1	3.5	4 / 4	1333/1600	6	3450	SR0PF	E1	77/67.4	HDG2500
	3.1	3.3	4 / 4	1333/1600	6	3350P	SR0WS	E1	69/67.4	-
	3.0	3.7	4 / 4	1333/1600	6	3550S	SR0P3	E1	65/69.1	HDG2500
	3.0	3.2	4 / 4	1333/1600	6	3330	SR0RQ	E1	77/67.4	HDG2500
	2.9	3.6	4 / 4	1333/1600	6	3475S	SR0PP	E1	65/69.1	HDG4000
	2.9	3.6	4 / 4	1333/1600	6	3470S	SR0TA	N0	65/69.1	HDG2500
	2.9	3.6	2 / 4	1333/1600	3	3470T	SR0RJ	L1	35/65.0	HDG2500 *
	2.8	3.5	4 / 4	1333/1600	6	3450S	SR0P2	E1	65/69.1	HDG2500
	2.7	3.5	4 / 4	1333/1600	6	3330S	SR0RR	E1	65/	HDG2500
2.3	3.2	4 / 4	1333/1600	6	3570T	SR0P1	E1	45/69.8	HDG2500	
15 2 nd Gen. (Sandy Bridge)	3.3	3.7	4 / 4	1066/1333	6	2550K	SR0QH	D2	95/72.6	-
	3.3	3.7	4 / 4	1066/1333	6	2500K	SR008	D2	95/72.6	HDG3000
	3.3	3.7	4 / 4	1066/1333	6	2500	SR00T	D2	95/72.6	HDG2000
	3.2	3.5	4 / 4	1066/1333	6	2450P	SR0G1	D2	95/72.6	-
	3.1	3.4	4 / 4	1066/1333	6	2380P	SR0G2	D2	95/72.6	-
	3.1	3.4	4 / 4	1066/1333	6	2400	SR00Q	D2	95/72.6	HDG2000
	3.0	3.3	4 / 4	1066/1333	6	2320	SR02L	D2	95/72.6	HDG2000
	2.9	3.2	4 / 4	1066/1333	6	2310	SR02K	D2	95/72.6	HDG2000
	2.8	3.1	4 / 4	1066/1333	6	2300	SR00D	D2	95/72.6	HDG2000
	2.7	3.7	4 / 4	1066/1333	6	2500S	SR009	D2	65/69.1	HDG2000
	2.7	3.5	2 / 4	1066/1333	3	2390T	SR065	Q0	35/65.0	HDG2000
	2.5	3.3	4 / 4	1066/1333	6	2405S	SR0BB	D2	65/69.1	HDG3000
	2.5	3.3	4 / 4	1066/1333	6	2400S	SR00S	D2	65/69.1	HDG2000
	2.3	3.3	4 / 4	1066/1333	6	2500T	SR00A	D2	45/69.8	HDG2000

Processor Brand	Clock [GHz]	Turbo [GHz]	Cores / Threads	Bus [MHz]	Cache [MB]	CPU Number	sSpec no.	Step	TG [W/°C]	Note
I3 3 rd Gen. (Ivy Bridge) (No vPRO)	3.5	-	2 / 4	1333/1600	3	3250	SR0YX	P0	55/65.3	HDG2500
	3.4	-	2 / 4	1333/1600	3	3245	SR0YL	L1	55/65.3	HDG4000
	3.4	-	2 / 4	1333/1600	3	3240	SR0RH	L1	55/65.3	HDG2500
	3.3	-	2 / 4	1333/1600	3	3225	SR0RF	L1	55/65.3	HDG4000
	3.3	-	2 / 4	1333/1600	3	3220	SR0RG	L1	55/65.3	HDG2500
	3.2	-	2 / 4	1333/1600	3	3210	SR0YY	P0	55/65.3	HDG2500
	3.0	-	2 / 4	1333/1600	3	3250T	SR0YW	P0	35/65.0	HDG2500
	2.9	-	2 / 4	1333/1600	3	3240T	SR0RK	L1	35/65.0	HDG2500
	2.8	-	2 / 4	1333/1600	3	3220T	SR0RE	L1	35/65.3	HDG2500
I3 2 nd Gen. (Sandy Bridge) (No vPRO)	3.4	-	2 / 4	1066/1333	3	2130	SR05W	Q0	65/69.1	HDG2000
	3.3	-	2 / 4	1066/1333	3	2125	SR0AY	J1	65/69.1	HDG3000
	3.3	-	2 / 4	1066/1333	3	2120	SR05Y	Q0	65/69.1	HDG2000
	3.1	-	2 / 4	1066/1333	3	2105	SR0BA	J1	65/69.1	HDG3000
	3.1	-	2 / 4	1066/1333	3	2100	SR05C	Q0	65/69.1	HDG2000
	3.1	-	2 / 4	1066/1333	3	2102	SR05D	Q0	65/69.1	HDG2000
	2.6	-	2 / 4	1066/1333	3	2120T	SR060	Q0	35/65.0	HDG2000
	2.5	-	2 / 4	1066/1333	3	2100T	SR05Z	Q0	35/65.0	HDG2000
Pentium	3.1	-	2 / 2	1066/1333	3	G870	SR057	Q0	65/69.1	HDG
	3.0	-	2 / 2	1066/1333	3	G860	SR058	Q0	65/69.1	HDG
	2.9	-	2 / 2	1066/1333	3	G850	SR05Q	Q0	65/69.1	HDG
	2.9	-	2 / 2	1066	3	G645	SR0RS	Q0	65/69.1	HDG
	2.8	-	2 / 2	1066/1333	3	G840	SR05P	Q0	65/69.1	HDG
	2.8	-	2 / 2	1066	3	G640	SR059	Q0	65/69.1	HDG
	2.7	-	2 / 2	1066	3	G632	SR05N	Q0	65/69.1	HDG
	2.7	-	2 / 2	1066	3	G630	SR05S	Q0	65/69.1	HDG
	2.8	-	2 / 2	1066/1333	3	G860T	SR0MF	Q0	35/65.0	HDG
	2.6	-	2 / 2	1066	3	G620	SR05R	Q0	65/69.1	HDG
	2.6	-	2 / 2	1066	3	G622	-	-	65/69.1	HDG
	2.5	-	2 / 2	1066	3	G645T	SR0S0	Q0	35/65.0	HDG
	2.4	-	2 / 2	1066	3	G640T	SR066	Q0	35/65.0	HDG
	2.2	-	2 / 2	1066	3	G620T	SR05T	Q0	35/65.0	HDG
2.3	-	2 / 2	1066	3	G630T	SR05U	Q0	35/65.0	HDG	
Celeron	2.7	-	2 / 2	1333	2	G1620	SR10L	P0	55	HDG *
	2.7	-	2 / 2	1066	2	G555	SR0RZ	Q0	65/69.1	HDG
	2.6	-	2 / 2	1333	2	G1610	SR10K	P0	55	HDG *
	2.6	-	2 / 2	1066	2	G550	SR061	Q0	65/69.1	HDG
	2.5	-	2 / 2	1066	2	G540	SR05J	Q0	65/69.1	HDG
	2.4	-	2 / 2	1066	2	G530	SR05H	Q0	65/69.1	HDG
	2.3	-	2 / 2	1333	2	G1610T	SR10M	P0	35/	HDG *
	2.2	-	2 / 2	1066	2	G550T	SR05V	Q0	35/65.0	HDG
	2.1	-	2 / 2	1066	2	G540T	SR05L	Q0	35/65.0	HDG
	2.0	-	2 / 2	1066	2	G530T	SR05K	Q0	35/65.0	HDG
	2.0	-	1 / 2	1066/1333	1.5	G470	SR0S7	Q0	35/65.5	HDG
	1.8	-	1 / 2	1066	1.5	G460	SR0GR	Q0	35/65.5	HDG
1.6	-	1 / 1	1066	1	G440	SR0BY	Q0	35/65.5	HDG	

(*) ECC not supported on KTQ67.

Not all CPUs, even of same type, support all functions ex. i7 3770K, i7 2600K, i5 3570K, 3450, 3450S, 3350P, 3330S, 3330 and i5 2500K, 2300,2310, 2320, 2380P, 2450P, 2550K doesn't support vPro while all other i7 and i5 does.

Most of the processors are supporting the Enhanced Intel® SpeedStep® which is improved SpeedStep technology for faster transition between voltage (power saving states) and frequency states with the result of improved power/performance balance. For more details see <http://ark.intel.com>

Intel® Turbo Boost Technology 2.0 is supported by i5 and i7, as indicated in above list of processors, and is enabling overclocking of all cores, when operated within the limits of thermal design power, temperature and current.


Sufficient cooling must be applied to the CPU in order to remove the effect as listed in above table (Thermal Guideline). The sufficient cooling is also depending on the maximum (worst-case) ambient operating temperature and the actual load of processor.



Warning: Make sure sufficient airflow is always present around the components located below the cooler. Different coolers are available on the market and some is not generating any airflow or is blocking the airflow around these components, causing reduced lifetime.


It is recommended to use a cooler like the Kontron PN 1046-6305 "KTQ67 Cooler".

The design of this cooler makes sure airflow is always present around the components below the cooler. Even if Fan is set to be off, it is still running a minimum RPM (Rotation Per Minute).



Air sucked in to the cooler

Air blown out of the cooler




Note: The temperature of the air blown out of the cooler should be 70°C maximum.

2.4 System Memory support

The KTQ67/Flex-Medical has four DDR3 UDIMM sockets. The sockets support the following memory features:

- 4x DDR3 1.5V UDIMM 240-pin
- Dual-channel with 2 UDIMM per channel
- Single/dual rank unbuffered 1066/1333MT/s (PC3-8500/PC3-10600)
From 256MB and up to 4x 8GB.
Note: Less than 4GB displayed in System Properties using 32bit OS
(Shared Video Memory/PCI resources is subtracted)
- SPD timings supported
- ECC not supported



The installed DDR3 DIMM should support the Serial Presence Detect (SPD) data structure. This allows the BIOS to read and configure the memory controller for optimal performance. If non-SPD memory is used, the BIOS will attempt to configure the memory settings, but performance and reliability may be impacted.

Memory Operating Frequencies

Regardless of the DIMM type used, the memory frequency will either be equal to or less than the processor system bus frequency. For example, if DDR3 1600 memory is used with a 1333 MHz system bus frequency processor, the memory clock will operate at 666 MHz. The table below lists the resulting operating memory frequencies based on the combination of DIMMs and processors.

DIMM Type	Module name	Memory Data transfers [Mill/s]	Processor system bus frequency [MHz]	Resulting memory clock frequency [MHz]	Peak transfer rate [MB/s]
DDR3 1066	PC3-8500	1066	1066 / 1333	533	8533
DDR3 1333	PC3-10600	1333	1333	666	10666
DDR3 1600	PC3-12800	1600	1333	666	10666

Notes: Kontron offers the following memory modules:


NEW SKU 04/2016*	SKU Name**	OLD SKU before 04/2016
1060-2490	DDR3-1066 DIMM 4GB	1054-3700
1060-2492	DDR3-1333 DIMM 2GB	1054-3702
1060-2494	DDR3-1333 DIMM 4GB	1054-3703
1060-2496	DDR3-1333 DIMM 8GB	1054-3704
1060-2498	DDR3-1600 DIMM 2GB	1054-3707
1060-2500	DDR3-1600 DIMM 4GB	1054-3708
1060-2488	DDR3-1600 DIMM 8GB	1052-5601

*SKU changes were caused by administrative issues only, no hardware changes.

**Named are always the min. requirements, the shipped memory can fulfill a higher performance level

It has not been verified that the combination of CPU supporting Bus Speed 1600 MHz and DDR3 1600 actually runs at 1600 MHz.

In order to support Intel ® AMT (Management Engine) SLOT A0 **must** always be populated. In case of using more than a single DIMM it is recommended to populate A0 + B0 first.



- ← DDR3 (SLOT B1)
- ← DDR3 (SLOT B0)
- ← DDR3 (SLOT A1)
- ← DDR3 (SLOT A0)

(Example Flex version)

2.5 KTQ67 Graphics Subsystem

The KTQ67 support Intel® HD Graphics 4000, 3000, 2500, 2000 or Intel® HD Graphics, depending on actual CPU. However please notice that even though an Ivy Bridge CPU supporting Triple Independent Displays are used then on the KTQ67 only Dual Independent Displays are supported.

Supports 2x DVI (single channel) via DVI-I and DVI-D connector and optionally LVDS.

Up to two displays (any two display outputs) can be activated at the same time and be used to implement dual independent display support or mirror display support. PCIe and PCI graphics cards can be used to replace on-board graphics or in combination with on-board graphics.

2.5.1 Intel® HD Graphics 3000 (example)

Features of the Intel HD Graphics 3000 build into the i3, i5 and i7 processors, includes:

- High quality graphics engine supporting
 - DirectX10.1 and OpenGL 3.0 compliant
 - Shader Model 4.1 support
 - Intel® Clear Video HD Technology
 - Intel® Quick Sync Video Technology
 - Intel® Flexible Display Interface (Intel® FDI)
 - Core frequency of 350 - 1300 (Turbo) MHz
 - Memory Bandwidth up to 21.3 GB/s
 - 12 3D Execution Units
 - 1.62 GP/s and 2.7 GP/S pixel rate (DP outputs)
 - Hardware Acceleration full MPEG2, full VC-1 and full AVC
 - Dynamic Video Memory Technology (DVMT) support up to 1720 MB

- LVDS panel Support (optional), 18/24 bit colours in up to WUXGA (1920x1200) @60 Hz and SPWG (VESA) colour coding. OpenLDI (JEIDA) colour coding is 18 bit with or without Dithering.

2.6 Power Consumption

In order to ensure safe operation of the board, the ATX12V power supply must monitor the supply voltage and shut down if the supplies are out of range – refer to the hardware manual for the actual power supply specification. The KTQ67 board is powered through the ATX/BTX connector and ATX+12V connector. Both connectors must be used in according to the ATX12V PSU standard.

The requirements to the supply voltages are as follows:

Supply	Min	Max	Note
VCC3.3	3.135V	3.465V	Should be $\pm 5\%$ for compliance with the ATX specification
Vcc	4.75V	5.25V	Should be $\pm 5\%$ for compliance with the ATX specification. Should be minimum 5.00V measured at USB connectors in order to meet the requirements of USB standard.
+12V	11.4V	12.6V	Should be $\pm 5\%$ for compliance with the ATX specification
-12V	-13.2V	-10.8V	Should be $\pm 10\%$ for compliance with the ATX specification
-5V	-5,50V	-4.5V	Not required for the KTQ67 board
5VSB	4.75V	5.25V	Should be $\pm 5\%$ for compliance with the ATX specification

More detailed Static Power Consumption

On the following pages the power consumption of the KTQ67 Board is measured under:

- 1- DOS, idle, mean
- 2- Windows7, Running 3DMARK 2005 & BiT 6, mean
- 3- S1, mean
- 4- S3, mean
- 5- S4, mean

The following items were used in the test setup:


Low Power Setup

Standard system configuration equipped with PCI card, Internal graphics, 2x SATA disks, Intel i3 CPU, 2x DIMM (1GB Modules), CRT Monitor, Keyboard & Mouse. 1x 1-4GB USB Flash Stick.

High Power Setup

Standard system configuration equipped with PCI card, PCIe4, PCIe16, miniPCIe WLAN, 4x SATA disks, Intel i7 CPU, 4x DIMM (2+2+2+1 Modules), CRT Monitor, Keyboard & Mouse, 4x 1-4GB USB Flash Stick.

1. 12V active cooler (Intel BOX).
2. USB Keyboard/Mouse Genius
3. CRT Sampo AlphaScan 912
4. 2.5" HDD Fujitsu MHY2120BH
5. ATX Fortron 400W
6. Tektronix TDS5104B
7. Tektronix TPCA300
8. Tektronix TCP312
9. Fluke 289
10. ATX rail switch



Note: The Power consumption of Display and HD are not included.

Low Power Setup results:

DOS Idle, Mean, No external load		
Supply	Current draw	Power consumption
+12V	0.258A	3.096W
+12V P4	1.363A	16.366W
+5V	1.417A	7.083W
+3V3	0.490A	1.618W
-12V	0.035A	0.416W
5VSB	0.006A	0.030W
Total		28.6W

Windows 7, mean 3DMARK2005 (first scene) & Bit 6		
Supply	Current draw	Power consumption
+12V	0.293A	3.516W
+12V P4	2.642A	31.702W
+5V	2.170A	10.850W
+3V3	0.443A	1.463W
-12V	0.037A	0.442W
5VSB	0.006A	0.030W
Total		48.0W

S1 Mode, Mean, No external load		
Supply	Current draw	Power consumption
+12V	0.212A	2.540W
+12V P4	0.238A	2.854W
+5V	0.828A	4.140W
+3V3	0.265A	0.878W
-12V	0.039A	0.469W
5VSB	0.006A	0.030W
Total		10.9W

S3 Mode, Mean, No external load		
Supply	Current draw	Power consumption
+12V	0A	0W
+12V P4	0A	0W
+5V	0A	0W
+3V3	0A	0W
-12V	0A	0W
5VSB	0.153A	0.765W
Total		0.77W

S4 Mode, Mean, No external load		
Supply	Current draw	Power consumption
+12V	0A	0W
+12V P4	0A	0W
+5V	0A	0W
+3V3	0A	0W
-12V	0A	0W
5VSB	0.120A	0.600W
Total		0.60W

High Power Setup results:

DOS Idle, Mean, No external load		
Supply	Current draw	Power consumption
+12V	1.978A	23.737W
+12V P4	1.827A	21.924W
+5V	2.061A	10.306W
+3V3	1.032A	3.404W
-12V	0.032A	0.384W
5VSB	0.006A	0.030W
Total		59.8W

Windows 7, mean 3DMARK2005 (first scene) & Bit 6		
Supply	Current draw	Power consumption
+12V	3.115A	37.380W
+12V P4	4.957A	59.484W
+5V	2.457A	12.285W
+3V3	1.659A	5.475W
-12V	0.038A	0.456W
5VSB	0.006A	0.030W
Total		115.1W


S1 Mode, Mean, No external load		
Supply	Current draw	Power consumption
+12V	2.179A	26.144W
+12V P4	0.594A	7.128W
+5V	1.076A	5.380W
+3V3	1.348A	4.447W
-12V	0.043A	0.516W
5VSB	0.006A	0.030W
Total		43.6W

S3 Mode, Mean, No external load		
Supply	Current draw	Power consumption
+12V	0A	0W
+12V P4	0A	0W
+5V	0A	0W
+3V3	0A	0W
-12V	0A	0W
5VSB	0.364A	1.820W
Total		1.82W


S4 Mode, Mean, No external load		
Supply	Current draw	Power consumption
+12V	0A	0W
+12V P4	0A	0W
+5V	0A	0W
+3V3	0A	0W
-12V	0A	0W
5VSB	0.295A	1.475W
Total		1.48W

3 Connector Locations

3.1 KTQ67/Flex-Medical – frontside



Notes: SATA0/SATA1 support up to 6GB/s and SATA2/SATA3/SATA4/SATA5 support up to 3GB/S. The LPT connector and the XDP connectors are not mounted in volume production.



4 Connector Definitions

The following sections provide pin definitions and detailed description of all on-board connectors.

The connector definitions follow the following notation:

Column name	Description
Pin	Shows the pin-numbers in the connector. The graphical layout of the connector definition tables is made similar to the physical connectors.
Signal	The mnemonic name of the signal at the current pin. The notation "XX#" states that the signal "XX" is active low.
Type	AI: Analogue Input. AO: Analogue Output. I: Input, TTL compatible if nothing else stated. IO: Input / Output. TTL compatible if nothing else stated. IOT: Bi-directional tristate IO pin. IS: Schmitt-trigger input, TTL compatible. IOC: Input / open-collector Output, TTL compatible. IOD: Input / Output, CMOS level Schmitt-triggered. (Open drain output) NC: Pin not connected. O: Output, TTL compatible. OC: Output, open-collector or open-drain, TTL compatible. OT: Output with tri-state capability, TTL compatible. LVDS: Low Voltage Differential Signal. PWR: Power supply or ground reference pins.
	Ioh: Typical current in mA flowing out of an output pin through a grounded load, while the output voltage is > 2.4 V DC (if nothing else stated). Iol: Typical current in mA flowing into an output pin from a VCC connected load, while the output voltage is < 0.4 V DC (if nothing else stated).
Pull U/D	On-board pull-up or pull-down resistors on input pins or open-collector output pins.
Note	Special remarks concerning the signal.

The abbreviation *TBD* is used for specifications which are not available yet or which are not sufficiently specified by the component vendors.


5 IO-Area Connectors

5.1 Display connectors (IO Area)

The KTQ67/Flex-Medical has two DVI connectors (stacked) and optionally one on-board LVDS panel interface. Both DVI connectors support single channel digital signals in a DVI-I type connector. Only the lower DVI connector support also analogue signals. Two graphic pipes are supported; meaning that up to two independent displays can be implemented using any two of the above mentioned graphic ports.

5.1.1 DVI (lower) connector – DVI-I


The DVI-I connector is based on stacked DVI-I connector type Kycon KVI42X-DA29S-S-A4N-W or similar. The lower connector is supporting both analogue and digital (single channel) signals.



Pin No.	Signal	Description	Type	Pull Up
1	TMDS Data 2-	Digital Red – (Link 1)	LVDS OUT	
2	TMDS Data 2+	Digital Red + (Link 1)	LVDS OUT	
3	TMDS Data 2/4 Shield		PWR	
4	N.C.		-	
5	N.C.		-	
6	DDC Clock	DDC Clock	IO	2K2
7	DDC Data	DDC Data	IO	2K2
8	VSYNC		AI	
9	TMDS Data 1-	Digital Green – (Link 1)	LVDS OUT	
10	TMDS Data 1+	Digital Green + (Link 1)	LVDS OUT	
11	TMDS Data 1/3 Shield		PWR	
12	N.C.		-	
13	N.C.		-	
14	+5V (55mA)	Power for monitor when in standby	PWR	
15	GND		PWR	
16	Hot Plug Detect	Hot Plug Detect	I	
17	TMDS Data 0-	Digital Blue – (Link 1) / Digital sync	LVDS OUT	
18	TMDS Data 0+	Digital Blue + (Link 1) / Digital sync	LVDS OUT	
19	TMDS Data 0/5 Shield		PWR	
20	N.C.		-	
21	N.C.		-	
22	TMDS Clock Shield		PWR	
23	TMDS Clock+	Digital clock + (Link 1)	LVDS OUT	
24	TMDS Clock-	Digital clock - (Link 1)	LVDS OUT	
C1	RED		AI	
C2	GREEN		AI	
C3	BLUE		AI	
C4	HSYNC		AI	
C5	GND		PWR	

5.1.2 DVI-D (upper) connector – DVI-D

The DVI-I connector is based on stacked DVI-I connector type Kycon KVI42X-DA29S-S-A4N-W or similar. It is supporting only digital signals (single channel).



Pin No.	Signal	Description	Type	Pull Up
1	TMDS Data 2-	Digital Red – (Link 1)	LVDS OUT	
2	TMDS Data 2+	Digital Red + (Link 1)	LVDS OUT	
3	TMDS Data 2/4 Shield		PWR	
4	N.C.		-	
5	N.C.		-	
6	DDC Clock	DDC Clock	IO	2K2
7	DDC Data	DDC Data	IO	2K2
8	N.C.		-	
9	TMDS Data 1-	Digital Green – (Link 1)	LVDS OUT	
10	TMDS Data 1+	Digital Green + (Link 1)	LVDS OUT	
11	TMDS Data 1/3 Shield		PWR	
12	N.C.		-	
13	N.C.		-	
14	+5V (55mA)	Power for monitor when in standby	PWR	
15	GND		PWR	
16	Hot Plug Detect	Hot Plug Detect	I	
17	TMDS Data 0-	Digital Blue – (Link 1) / Digital sync	LVDS OUT	
18	TMDS Data 0+	Digital Blue + (Link 1) / Digital sync	LVDS OUT	
19	TMDS Data 0/5 Shield		PWR	
20	N.C.		-	
21	N.C.		-	
22	TMDS Clock Shield		PWR	
23	TMDS Clock+	Digital clock + (Link 1)	LVDS OUT	
24	TMDS Clock-	Digital clock - (Link 1)	LVDS OUT	
C1 - C5	N.C.		-	

5.2 Ethernet Connectors (IO Area)

The KTQ67/Flex-Medical support two channels of 10/100/1000Mb Ethernet ports, ETH1 and ETH2. Both ports are Galvanic Isolated. ETH1 (left Ethernet connector) is based on Intel® Lewisville 82579LM Gigabit PHY with AMT 8.0 support and ETH2 (right Ethernet connector) is based on Intel® Hartwell 82574L PCI Express controller.

In order to achieve the specified performance of the Ethernet port, minimum Category 5 twisted pair cables must be used with 10/100MB and minimum Category 5E, 6 or 6E with 1Gb LAN networks.

The signals for the Ethernet ports are as follows:

Signal	Description
MDI[0]+ / MDI[0]-	In MDI mode, this is the first pair in 1000Base-T, i.e. the BI_DA+/- pair, and is the transmit pair in 10Base-T and 100Base-TX. In MDI crossover mode, this pair acts as the BI_DB+/- pair, and is the receive pair in 10Base-T and 100Base-TX.
MDI[1]+ / MDI[1]-	In MDI mode, this is the second pair in 1000Base-T, i.e. the BI_DB+/- pair, and is the receive pair in 10Base-T and 100Base-TX. In MDI crossover mode, this pair acts as the BI_DA+/- pair, and is the transmit pair in 10Base-T and 100Base-TX.
MDI[2]+ / MDI[2]-	In MDI mode, this is the third pair in 1000Base-T, i.e. the BI_DC+/- pair. In MDI crossover mode, this pair acts as the BI_DD+/- pair.
MDI[3]+ / MDI[3]-	In MDI mode, this is the fourth pair in 1000Base-T, i.e. the BI_DD+/- pair. In MDI crossover mode, this pair acts as the BI_DC+/- pair.

Note: MDI = Media Dependent Interface.

The pinout of the RJ45 connectors is as follows:


Signal	PIN	Type	Ioh/Iol	Note
MDI3-	7			
MDI3+	6			
MDI1-	5			
MDI2-	4			
MDI2+	3			
MDI1+	2			
MDI0-	1			
MDI0+	8			

5.3 USB Connectors (IO Area)

The KTQ67/Flex-Medical board contains two EHCI (Enhanced Host Controller Interface) host controllers (EHC11 and EHC12) that support up to fourteen USB 2.0 ports, twelve are available on the KTQ67/Flex-Medical. The USB2.0 ports allowing data transfers up to 480Mb/s and legacy Keyboard/Mouse and wakeup from sleep states are supported. Over-current detection on all fourteen USB ports is supported. The following USB connectors are available in the IO Area.

USB Port 0 - 3 (all via EHC11) are supplied on the combined USB0, USB1, USB2 and USB3 connector.

Note: It is required to use only HiSpeed USB cable, specified in USB2.0 standard:



5.3.1 USB Connector 0/1/2/3 (USB0/1/2/3)

USB Ports 0, 1, 2 and 3 are mounted in a common stack connector.

Note	Type	Signal	PIN				Signal	Type	Note
1	PWR	5V/SB5V	1	2	3	4	GND	PWR	
	IO	USB0-					USB0+	IO	
1	PWR	5V/SB5V	1	2	3	4	GND	PWR	
	IO	USB1-					USB1+	IO	
1	PWR	5V/SB5V	1	2	3	4	GND	PWR	
	IO	USB2-					USB2+	IO	
1	PWR	5V/SB5V	1	2	3	4	GND	PWR	
	IO	USB3-					USB3+	IO	

Note 1: In order to meet the requirements of USB standard, the 5V input supply must be at least 5.00V.

Signal	Description
USB0+ USB0- USB1+ USB1- USB2+ USB2- USB3+ USB3-	Differential pair works as Data/Address/Command Bus.
5V/SB5V	5V supply for external devices. SB5V is supplied during powerdown to allow wakeup on USB device activity. Protected by resettable 1A fuse for each USB ports.

5.4 COM1 and COM2 Connectors (IO Area)

Four RS232 serial ports are available on the KTQ67/Flex-Medical, COM1 and COM2 are available in the IO Area while the other COM ports are available on internal pin header connectors.

The typical definition of the signals in the COM ports is as follows:

Signal	Description
TxD	Transmitted Data, sends data to the communications link. The signal is set to the marking state (-12V) on hardware reset when the transmitter is empty or when loop mode operation is initiated.
RxD	Received Data, receives data from the communications link.
DTR	Data Terminal Ready, indicates to the modem etc. that the on-board UART is ready to establish a communication link.
DSR	Data Set Ready, indicates that the modem etc. is ready to establish a communications link.
RTS	Request To Send, indicates to the modem etc. that the on-board UART is ready to exchange data.
CTS	Clear To Send, indicates that the modem or data set is ready to exchange data.
DCD	Data Carrier Detect, indicates that the modem or data set has detected the data carrier.
RI	Ring Indicator, indicates that the modem has received a ringing signal from the telephone line.

The pinout of Serial ports COM1 is as follows:

Note	Pull U/D	Ioh/Iol	Type	Signal	PIN	Signal	Type	Ioh/Iol	Pull U/D	Note
	-	-	PWR	GND	5					
					9	RI	I	-	/5K	
	-		O	DTR	4					
					8	CTS	I	-	/5K	
	-		O	TxD	3					
					7	RTS	O		-	
	/5K	-	I	RxD	2					
					6	DSR	I	-	/5K	
	/5K	-	I	DCD	1					

6 Internal Connectors

6.1 Power Connector (ATX/BTXPWR)

The KTQ67 board is designed to be supplied from a standard ATX (or BTX) power supply. Use of BTX supply is not required for operation, but may be required to drive high-power PCIe cards.

ATX/ BTX Power Connector (J45):

Note	Type	Signal	PIN		Signal	Type	Note
	PWR	3V3	12	24	GND	PWR	
	PWR	+12V	11	23	5V	PWR	
	PWR	+12V	10	22	5V	PWR	
	PWR	SB5V	9	21	5V	PWR	
	I	P_OK	8	20	-5V	PWR	1
	PWR	GND	7	19	GND	PWR	
	PWR	5V	6	18	GND	PWR	
	PWR	GND	5	17	GND	PWR	
	PWR	5V	4	16	PSON#	OC	
	PWR	GND	3	15	GND	PWR	
	PWR	3V3	2	14	-12V	PWR	
	PWR	3V3	1	13	3V3	PWR	

Note 1: -5V supply is not used on-board.

See chapter “Power Consumption” regarding input tolerances on 3.3V, 5V, SB5V, +12 and -12V (also refer to ATX specification version 2.2).

ATX+12V-4pin Power Connector (J46):

Note	Type	Signal	PIN		Signal	Type	Note
	PWR	GND	2	4	+12V	PWR	1
	PWR	GND	1	3	+12V	PWR	1

Note 1: Use of the 4-pin ATX+12V Power Connector is required.

Signal	Description
P_OK	<p>P_OK is a power good signal and should be asserted high by the power supply to indicate that the +5VDC and +3.3VDC outputs are above the undervoltage thresholds of the power supply. When this signal is asserted high, there should be sufficient energy stored by the converter to guarantee continuous power operation within specification. Conversely, when the output voltages fall below the undervoltage threshold, or when mains power has been removed for a time sufficiently long so that power supply operation is no longer guaranteed, P_OK should be de-asserted to a low state. The recommended electrical and timing characteristics of the P_OK (PWR_OK) signal are provided in the <i>ATX12V Power Supply Design Guide</i>.</p> <p>It is strongly recommended to use an ATX or BTX supply in order to implement the supervision of the 5V and 3V3 supplies. These supplies are not supervised on-board.</p>
PS_ON#	Active low open drain signal from the board to the power supply to turn on the power supply outputs. Signal must be pulled high by the power supply.

6.2 Fan Connectors (FAN_CPU) (J28) and (FAN_SYS) (J29)

The **FAN_CPU** is used for the connection of the FAN for the CPU.

The **FAN_SYS** can be used to power, control and monitor a fan for chassis ventilation etc.

The 4pin header is recommended to be used for driving 4-wire type Fan in order to implement FAN speed control. 3-wire Fan is also possible, but no fan speed control is integrated.

4-pin Mode:

PIN	Signal	Type	Ioh/Iol	Pull U/D	Note
1	CONTROL	O	-	-	
2	SENSE	I	-	4K7	
3	+12V	PWR	-	-	
4	GND	PWR	-	-	

Signal	Description
CONTROL	PWM signal for FAN speed control
SENSE	Tacho signal from the fan for supervision. The signals shall be generated by an open collector transistor or similar. On-board is a pull-up resistor 4K7 to +12V. The signal has to be pulsed, typically twice per rotation.
12V	+12V supply for fan. A maximum of 2000mA can be supplied from this pin.
GND	Power Supply GND signal

3-pin Mode:

PIN	Signal	Type	Ioh/Iol	Pull U/D	Note
-					
2	SENSE	I	-	4K7	
3	+12V	PWR	-	-	
4	GND	PWR	-	-	

Signal	Description
SENSE	Tacho signal from the fan for supervision. The signals shall be generated by an open collector transistor or similar. On-board is a pull-up resistor 4K7 to +12V. The signal has to be pulsed, typically twice per rotation.
12V	+12V supply for fan. A maximum of 2000mA can be supplied from this pin.
GND	Power Supply GND signal

6.3 PS/2 Keyboard and Mouse connector (KBDMSE) (J15)

Attachment of a PS/2 keyboard/mouse can be done through the pinrow connector KBDMSE (J15). Both interfaces utilize open-drain signalling with on-board pull-up.

The PS/2 mouse and keyboard is supplied from SB5V when in standby mode in order to enable keyboard or mouse activity to bring the system out from power saving states. The supply is provided through a 1.1A resettable fuse.

PIN	Signal	Type	Ioh/Iol	Pull U/D	Note
1	KBDCLK	IOD	/14mA	2K7	
2	KBDDAT	IOD	/14mA	2K7	
3	MSCLK	IOD	/14mA	2K7	
4	MSDAT	IOD	/14mA	2K7	
5	5V/SB5V	PWR	-	-	
6	GND	PWR	-	-	

Signal Description – Keyboard & and mouse Connector (KBDMSE).

Signal	Description
MSCLK	Bi-directional clock signal used to strobe data/commands from/to the PS/2 mouse.
MSDAT	Bi-directional serial data line used to transfer data from or commands to the PS/2 mouse.
KDBCLK	Bi-directional clock signal used to strobe data/commands from/to the PC-AT keyboard.
KBDDAT	Bi-directional serial data line used to transfer data from or commands to the PC-AT keyboard.

6.4 Display connectors (Internal)

The KTQ67 provides optionally internal on-board LVDS panel interface. For IO Area Display Connectors (DVI-D and DVI-I), see earlier section.

Two graphic pipes are supported; meaning that up to two independent displays can be implemented using any two display connectors in IO Area - and Internal (LVDS) connector (optionally).

6.4.1 LVDS Flat Panel Connector (LVDS) (J39) (optionally)

Two graphic pipes are supported; meaning that up to two independent displays can be implemented using any two of display connectors (IO Area - and Internal connectors).

Note	Type	Signal	PIN	Signal	Type	Note
Max. 0.5A	PWR	+12V	1 2	+12V	PWR	Max. 0.5A
Max. 0.5A	PWR	+12V	3 4	+12V	PWR	Max. 0.5A
Max. 0.5A	PWR	+12V	5 6	GND	PWR	Max. 0.5A
Max. 0.5A	PWR	+5V	7 8	GND	PWR	Max. 0.5A
Max. 0.5A	PWR	LCDVCC	9 10	LCDVCC	PWR	Max. 0.5A
2K2Ω, 3.3V	OT	DDC CLK	11 12	DDC DATA	OT	2K2Ω, 3.3V
3.3V level	OT	BKLTCTL	13 14	VDD ENABLE	OT	3.3V level
3.3V level	OT	BKLTEN#	15 16	GND	PWR	Max. 0.5A
	LVDS	LVDS A0-	17 18	LVDS A0+	LVDS	
	LVDS	LVDS A1-	19 20	LVDS A1+	LVDS	
	LVDS	LVDS A2-	21 22	LVDS A2+	LVDS	
	LVDS	LVDS ACLK-	23 24	LVDS ACLK+	LVDS	
	LVDS	LVDS A3-	25 26	LVDS A3+	LVDS	
Max. 0.5A	PWR	GND	27 28	GND	PWR	Max. 0.5A
	LVDS	LVDS B0-	29 30	LVDS B0+	LVDS	
	LVDS	LVDS B1-	31 32	LVDS B1+	LVDS	
	LVDS	LVDS B2-	33 34	LVDS B2+	LVDS	
	LVDS	LVDS BCLK-	35 36	LVDS BCLK+	LVDS	
	LVDS	LVDS B3-	37 38	LVDS B3+	LVDS	
Max. 0.5A	PWR	GND	39 40	GND	PWR	Max. 0.5A

Note: The KTQ67 on-board LVDS connector supports single/dual channel, 18/24bit SPWG panels up to resolution 1600x1200 or 1920x1080 (1920x1200 with limited frame rate is possible).

Signal Description – LVDS Flat Panel Connector:

Signal	Description
LVDS A0..A3	LVDS A Channel data
LVDS ACLK	LVDS A Channel clock
LVDS B0..B3	LVDS B Channel data
LVDS BCLK	LVDS B Channel clock
BKLTCTL	Backlight control (1), PWM signal to implement voltage in the range 0-3.3V
BKLTEN#	Backlight Enable signal (active low) (2)
VDD ENABLE	Output Display Enable.
LCDVCC	VCC supply to the display. Power-on/off sequencing depending on selected (in BIOS setup) display type. 5V or 3.3V selected in BIOS setup. Maximum load is 1A.
DDC CLK	DDC Channel Clock

Notes: Windows API will be available to operate the BKLTCTL signal. Some Inverters have a limited voltage range 0- 2.5V for this signal: If voltage is > 2.5V the Inverter might latch up. Some Inverters generates noise on the BKLTCTL signal, resulting in making the LVDS transmission failing (corrupted picture on the display). By adding a 1Kohm resistor in series with this signal, mounted in the Inverter end of the cable kit, the noise is limited and the picture is stable. If the Backlight Enable is required to be active high, then check the following BIOS Chipset setting: Backlight Signal Inversion = Enabled.

6.5 SATA (Serial ATA) Disk interface (J22 – J27)

The KTQ67 board has an integrated SATA Host controller (integrated in the PCH) that supports independent DMA operation on six ports. One device can be installed on each port for a maximum of six SATA devices. A point-to-point interface (SATA cable) is used for host to device connections. Data transfer rates of up to 6.0Gb/s (typically 600MB/s) on SATA0 and SATA1 (blue connectors) and 3.0Gb/s (typically 300MB/s) on SATA2, SATA3, SATA4 and SATA5 (black connectors). In case mSATA is used then the SATA2 is disabled.

The SATA controller supports:

- 2 to 6-drive RAID 0 (data striping)
- 2-drive RAID 1 (data mirroring)
- 3 to 6-drive RAID 5 (block-level striping with parity).
- 4-drive RAID 10 (data striping and mirroring)
- 2 to 6-drive matrix RAID (different parts of a single drive can be assigned to different RAID devices).
- AHCI (Advanced Host Controller Interface)
- NCQ (Native Command Queuing). NCQ is for faster data access.
- Hot Swap
- Intel® Rapid Recover Technology
- 2 – 256TB volume (Data volumes only)
- Capacity expansion
- TRIM in Windows 7 (in AHCI and RAID mode for drives not part of a RAID volume). (TRIM is for SSD data garbage handling).

The RAID (Redundant Array of Independent Drives) functionality is based on a firmware system with support for RAID modes 0 1, 5 and 10.

SATA connector pinning:

The pinout of SATA ports SATA0 (J27), SATA1 (J26), SATA2 (J25), SATA3 (J24), SATA4 (J23) and SATA5 (J22) is as follows:

PIN	Signal	Type	Ioh/Iol	Pull U/D	Note
1	GND	PWR	-	-	
2	SATA* TX+				
3	SATA* TX-				
4	GND	PWR	-	-	
5	SATA* RX-				
6	SATA* RX+				
7	GND	PWR	-	-	

The signals used for the primary SATA hard disk interface are the following:

Signal	Description
SATA* RX+ SATA* RX-	Host transmitter differential signal pair
SATA* TX+ SATA* TX-	Host receiver differential signal pair


“*” specifies 0, 1, 2, 3, 4, 5 depending on SATA port.

6.6 USB Connectors (USB)

The KTQ67 board contains two EHCI (Enhanced Host Controller Interface) host controllers (EHCI1 and EHCI2) that support up to fourteen USB 2.0 ports allowing data transfers up to 480Mb/s. Legacy Keyboard/Mouse and wakeup from sleep states are supported. Over-current detection on all fourteen USB ports is supported. The following USB ports are available on Internal Pinrows:

USB Port 6 and 7 (via EHCI1) are supplied on the USB6/7 internal pinrow FRONTPNL connector.
 USB Port 8 and 9 (via EHCI2) are supplied on the USB8/9 internal pinrow connector.
 USB Port 10 and 11 (via EHCI2) are supplied on the USB10/11 internal pinrow connector.
 USB Port 12 and 13 (via EHCI2) are supplied on the USB12/13 internal pinrow connector.

Note: It is required to use only HiSpeed USB cable, specified in USB2.0 standard:



6.6.1 USB Connector 6/7

See Frontpanel Connector (FRONTPNL) description.

6.6.2 USB Connector 8/9 (USB8/9) (J18)

USB Ports 8 and 9 are supplied on the internal USB8/9 pinrow connector J18.

Note	Type	Signal	PIN	Signal	Type	Note
1	PWR	5V/SB5V	1 2	5V/SB5V	PWR	1
	IO	USB8-	3 4	USB9-	IO	
	IO	USB8+	5 6	USB9+	IO	
	PWR	GND	7 8	GND	PWR	
	NC	KEY	9 10	NC	NC	

Signal	Description
USB8+ USB8- USB9+ USB9-	Differential pair works as Data/Address/Command Bus.
5V/SB5V	5V supply for external devices. SB5V is supplied during powerdown to allow wakeup on USB device activity. Protected by resettable 1A fuse covering both USB ports.

6.6.3 USB Connector 10/11 (USB10/11) (J17)

USB Ports 10 and 11 are supplied on the internal USB10/11 pinrow connector J17.

Note	Type	Signal	PIN		Signal	Type	Note
1	PWR	5V/SB5V	1	2	5V/SB5V	PWR	1
	IO	USB10-	3	4	USB11-	IO	
	IO	USB10+	5	6	USB11+	IO	
	PWR	GND	7	8	GND	PWR	
	NC	KEY	9	10	NC	NC	

Signal	Description
USB10+ USB10- USB11+ USB11-	Differential pair works as Data/Address/Command Bus.
5V/SB5V	5V supply for external devices. SB5V is supplied during powerdown to allow wakeup on USB device activity. Protected by resettable 1A fuse covering both USB ports.

6.6.4 USB Connector 12/13 (USB12/13) (J16)

USB Ports 12 and 13 are supplied on the internal USB12/13 pinrow connector J16.

Note	Type	Signal	PIN		Signal	Type	Note
1	PWR	5V/SB5V	1	2	5V/SB5V	PWR	1
	IO	USB12-	3	4	USB13-	IO	
	IO	USB12+	5	6	USB13+	IO	
	PWR	GND	7	8	GND	PWR	
	NC	KEY	9	10	NC	NC	

Signal	Description
USB12+ USB12- USB13+ USB13-	Differential pair works as Data/Address/Command Bus.
5V/SB5V	5V supply for external devices. SB5V is supplied during powerdown to allow wakeup on USB device activity. Protected by resettable 1A fuse covering both USB ports.

Note 1: In order to meet the requirements of USB standard, the 5V input supply must be at least 5.00V.

6.7 Serial COM3 – COM4 Ports (J20, J21)

Three RS232 serial ports are available on the KTQ67 via pin-row connector. (COM1 and COM2 are in the IO area and is based on standard DB9 connector, see other section for more info).

The typical definition of the signals in the COM ports is as follows:

Signal	Description
TxD	Transmitted Data, sends data to the communications link. The signal is set to the marking state (-12V) on hardware reset when the transmitter is empty or when loop mode operation is initiated.
RxD	Received Data, receives data from the communications link.
DTR	Data Terminal Ready, indicates to the modem etc. that the on-board UART is ready to establish a communication link.
DSR	Data Set Ready, indicates that the modem etc. is ready to establish a communications link.
RTS	Request To Send, indicates to the modem etc. that the on-board UART is ready to exchange data.
CTS	Clear To Send, indicates that the modem or data set is ready to exchange data.
DCD	Data Carrier Detect, indicates that the modem or data set has detected the data carrier.
RI	Ring Indicator, indicates that the modem has received a ringing signal from the telephone line.

The pinout of Serial ports COM3 (J19) and COM4 (J21) is as follows:

Note	Ioh/Iol	Type	Signal	PIN		Signal	Type	Ioh/Iol	Note
	-	I	DCD	1	2	DSR	I	-	
	-	I	RxD	3	4	RTS	O		
		O	TxD	5	6	CTS	I	-	
		O	DTR	7	8	RI	I	-	
	-	PWR	GND	9	10	5V	PWR	-	1

Note 1: The COM3 and COM4 5V supply is fused with common 1.1A resettable fuse.

DB9 adapter cables (PN 821016 200mm long and 821017 100mm long) are available for implementing standard COM ports on chassis.

6.8 Audio Connector

The on-board Audio circuit implements 7.1+2 Channel High Definition Audio with UAA (Universal Audio Architecture), featuring five 24-bit stereo DACs and three 20-bit stereo ADCs.

6.8.1 Line2 and Mic2

Line2 and Mic2 are accessible via Front Panel Connector, see Front Panel connector description.

6.8.1 Audio Header Connector (AUDIO_HEAD) (J47)

Note	Type	Signal	PIN		Signal	Type	Note
	AO	LFE-OUT	1	2	CEN-OUT	AO	
	PWR	AAGND	3	4	AAGND	PWR	
	AO	FRONT-OUT-L	5	6	FRONT-OUT-R	AO	
	PWR	AAGND	7	8	AAGND	PWR	
	AO	REAR-OUT-L	9	10	REAR-OUT-R	AO	
	AO	SIDE-OUT-L	11	12	SIDE-OUT-R	AO	
	PWR	AAGND	13	14	AAGND	PWR	
	AI	MIC1-L	15	16	MIC1-R	AI	
	PWR	AAGND	17	18	AAGND	PWR	
		LINE1-L	19	20	LINE1-R		
	NC	NC	21	22	AAGND	PWR	
	PWR	GND	23	24	NC	NC	
	O	SPDIF-OUT	25	26	GND	PWR	

Signal	Description
FRONT-OUT-L	Front Speakers (Speaker Out Left).
FRONT-OUT-R	Front Speakers (Speaker Out Right).
REAR-OUT-L	Rear Speakers (Surround Out Left).
REAR-OUT-R	Rear Speakers (Surround Out Right).
SIDE-OUT-L	Side speakers (Surround Out Left)
SIDE-OUT-R	Side speakers (Surround Out Right)
CEN-OUT	Center Speaker (Center Out channel).
LFE-OUT	Subwoofer Speaker (Low Freq. Effect Out).
NC	No connection
MIC1	MIC Input 1
LINE1	Line 1 signals
F-SPDIF-OUT	S/PDIF Output
AAGND	Audio Analogue ground

6.9 Power Button Connector (PWRBTN) (J48)

PIN	Signal	Type	Ioh/Iol	Pull U/D	Note
1	PWRBTN_IN#	I	-	1K1	
2	GND	PWR	-	-	
3	PWR_LED	O	-	470	
4	SLEEP_LED	O	-	470	

Signal	Description
PWRBTN_IN#	Power Button In. Toggle this signal low to start the ATX/TX PSU and boot the board.
PWR_LED	PoWeR LED, active high (+5V via 470Ω).
SLEEP_LED	Sleep LED, active high (+5V via 470Ω).

6.10 Front Panel Connector (FRONTPNL) (J36)

Note	Pull U/D	Ioh/Iol	Type	Signal	PIN	Signal	Type	Ioh/Iol	Pull U/D	Note
	-	-	PWR	USB6/7_5V	1 2	USB6/7_5V	PWR	-	-	
	-	-		USB6-	3 4	USB7-		-	-	
	-	-		USB6+	5 6	USB7+		-	-	
	-	-	PWR	GND	7 8	GND	PWR	-	-	
	-	-	NC	NC	9 10	LINE2-L		-	-	
	-	-	PWR	+5V	11 12	+5V	PWR	-	-	
	-	/7mA	O	SATA_LED#	13 14	SUS_LED	O	7mA	-	
	-	-	PWR	GND	15 16	PWRBTN_IN#	I	-	1K1	
	4K7	-	I	RSTIN#	17 18	GND	PWR	-	-	
	-	-	PWR	SB3V3	19 20	LINE2-R		-	-	
	-	-	PWR	AGND	21 22	AGND	PWR	-	-	
	-	-	AI	MIC2-L	23 24	MIC2-R	AI	-	-	

Signal	Description
USB10/11_5V	5V supply for external devices. SB5V is supplied during power down to allow wakeup on USB device activity. Protected by resettable 1.1A fuse covering both USB ports.
USB1+ USB1-	Universal Serial Bus Port 1 Differentials: Bus Data/Address/Command Bus.
USB3+ USB3-	Universal Serial Bus Port 3 Differentials: Bus Data/Address/Command Bus.
+5V	Maximum load is 1A or 2A per pin if using IDC connector flat cable or crimp terminals respectively.
SATA_LED#	SATA Activity LED, active low signal (via 470Ω). Recommended is using Low Power LED like HLMP4700 with anode connected to +5V (pin 11). When red color LED is used, possible weak glowing could be noticed when the LED supposed to be off. In order to eliminate this problem a resistor 3K3 can be connected in parallel with the LED or a diode can be connected in series with the LED.
SUS_LED	Suspend Mode LED (active high signal). Output 3.3V via 470Ω.
PWRBTN_IN#	Power Button In. Toggle this signal low to start the ATX / BTX PSU and boot the board.
RSTIN#	Reset Input. When pulled low for a minimum 16ms, the reset process will be initiated. The reset process continues even though the Reset Input is kept low.
LINE2	Line2 is second stereo Line signals
MIC2	MIC2 is second stereo microphone input.
SB3V3	Standby 3.3V voltage
AGND	Analogue Ground for Audio

Note: In order to meet the requirements of USB standard, the 5V input supply must be at least 5.00V.

6.11 Feature Connector (FEATURE) (J30)

Note	Pull U/D	Ioh/Iol	Type	Signal	PIN	Signal	Type	Ioh/Iol	Pull U/D	Note
2	2M/	-	I	CASE_OPEN#	1 2	SMBC		/4mA	10K/	1
	-	25/25mA	O	S5#	3 4	SMBD		/4mA	10K/	1
	-	25/25mA	O	PWR_OK	5 6	EXT_BAT	PWR	-	-	
	-		O	FAN3OUT	7 8	FAN3IN	I	-	-	
	-	-	PWR	SB3V3	9 10	SB5V	PWR	-	-	
	-		IOT	GPIO0	11 12	GPIO1	IOT			
	-		IOT	GPIO2	13 14	GPIO3	IOT			
	-		IOT	GPIO4	15 16	GPIO5	IOT			
	-		IOT	GPIO6	17 18	GPIO7	IOT			
	-	-	PWR	GND	19 20	GND	PWR	-	-	
	-		I	GPIO8	21 22	GPIO9	I			
	-		I	GPIO10	23 24	GPIO11	I			
	-		I	GPIO12	25 26	GPIO13	IOT			
	-		IOT	GPIO14	27 28	GPIO15	IOT			
	-		IOT	GPIO16	29 30	GPIO17	IOT			
	-	-	PWR	GND	31 32	GND	PWR	-	-	
	-	8/8mA	O	EGCLK	33 34	EGCS#	O	8/8mA	-	
	-	8/8mA		EGAD	35 36	TMA0	O			
	-		PWR	+12V	37 38	GND	PWR	-	-	
	-		O	FAN4OUT	39 40	FAN4IN	I	-	-	
	-	-	PWR	GND	41 42	GND	PWR	-	-	
	-	-	PWR	GND	43 44	S3#	O	25/25mA	-	

Notes: 1. Pull-up to +3V3Dual (+3V3 or SB3V3). 2. Pull-up to on-board Battery.

Signal	Description
CASE_OPEN#	CASE OPEN, used to detect if the system case has been opened. This signal's status is readable, so it may be used like a GPI when the Intruder switch is not required.
SMBC	SMBus Clock signal
SMBD	SMBus Data signal
S3#	S3 sleep mode, active low output, optionally used to deactivate external system.
S5#	S5 sleep mode, active low output, optionally used to deactivate external system.
PWR_OK	PoWeR OK, signal is high if no power failures are detected. (This is not the same as the P_OK signal generated by ATX PSU).
EXT_BAT	(EXTERNAL BATTERY) option for connecting + terminal of an external primary cell battery (2.5 - 3.47 V) (- terminal connected to GND). The external battery is protected against charging and can be used with or without the on-board battery installed.
FAN3OUT	FAN 3 speed control OUTPUT, 3.3V PWM signal can be used as Fan control voltage.
FAN3IN	FAN3 Input. 0V to +3V3 amplitude Fan 3 tachometer input.
FAN4OUT	FAN 4 speed control OUTPUT, 3.3V PWM signal can be used as Fan control voltage.
FAN4IN	FAN4 Input. 0V to +3V3 amplitude Fan 3 tachometer input.
SB3V3	Max. load is 0.75A (1.5A < 1 sec.)
SB5V	StandBy +5V supply.
GPIO0..17	General Purpose Inputs / Output. These Signals may be controlled or monitored through the use of the KT-API-V2 (Application Programming Interface).
EGCLK	Extend GPIO Clock signal
EGAD	Extend GPIO Address Data signal
EGCS#	Extend GPIO Chip Select signal, active low
TMA0	Timer Output
+12V	Max. load is 0.75A (1.5A < 1 sec.)

GPIO in more details.


The GPIO's are controlled via the ITE IT8516F Embedded Controller. Each GPIO has 100pF to ground, clamping Diode to 3V3 and has multiplexed functionality. Some pins can be DAC (Digital to Analogue Converter output), PWM (Pulse Width Modulated signal output), ADC (Analogue to Digital Converter input), TMRI (Timer Counter Input), WUI (Wake Up Input), RI (Ring Indicator Input) or some special function.

Signal	IT8516F pin name	Type	Description
GPIO0	DAC0/GPJ0	AO/IOS	
GPIO1	DAC1/GPJ1	AO/IOS	
GPIO2	DAC2/GPJ2	AO/IOS	
GPIO3	DAC3/GPJ3	AO/IOS	
GPIO4	PWM2/GPA2	O8/IOS	
GPIO5	PWM3/GPA3	O8/IOS	
GPIO6	PWM4/GPA4	O8/IOS	
GPIO7	PWM5/GPA5	O8/IOS	
GPIO8	ADC0/GPI0	AI/IS	
GPIO9	ADC1/GPI1	AI/IS	
GPIO10	ADC2/GPI2	AI/IS	
GPIO11	ADC3/GPI3	AI/IS	
GPIO12	ADC4/WUI28/GPI4	AI/IS/IS	
GPIO13	RI1#/WUI0/GPD0	IS/IS/IOS	
GPIO14	RI2#/WUI1/GPD1	IS/IS/IOS	
GPIO15	TMRI0/WUI2/GPC4	IS/IS/IOS	
GPIO16	TMRI1/WUI3/GPC6	IS/IS/IOS	
GPIO17	L80HLAT/BAO/WUI24/GPE0	O4/O4/IS/IOS	

6.12 "Load Default BIOS Settings" Jumper (J11)

The "Load Default BIOS Settings" Jumper (J11) can be used to recover from incorrect BIOS settings. As an example, incorrect BIOS settings causing no display to turn on can be erased by the Jumper.

The Jumper has 3 positions: Pin 1-2, Pin2-3 (default position) and not mounted.



Warning: Don't leave the jumper in position 1-2, otherwise if power is disconnected, the battery will fully deplete within a few weeks.

J11			Description
Pin3	Pin2	Pin1	
		●	Default position (same as no function)
●			Load Default BIOS Settings
●	●	●	No function

To Load Default BIOS Settings:

1. Turn off power completely (no SB5V).
2. Move the Jumper to pin 1-2 for ~10 seconds.
3. Move the Jumper back to position 2-3 (default position).
4. Turn on power (use the Power On Button if required to boot).
5. Motherboard might automatically reboot a few times. Wait until booting is completed.

6.13 ClrRTC (J12)

The ClrRTC (J12) connector is not used and may not be available. Do not install any jumper.

J12			Description
Pin3	Pin2	Pin1	
		●	No function
●			Clear ME CMOS settings (same effect as removing Lithium battery for 1 minute)
●	●	●	No function


6.14 SPI Recover Jumper (J41)

The SPI Recover Jumper is used to select BIOS Recovery SPI Flash instead of the BIOS Default SPI Flash.

Normally Jumper is not installed and board boots on the BIOS Default SPI Flash.

Only in case the Default BIOS gets corrupted and board do not boot:

Then turn off power
Install Jumper (J41)
Try rebooting



After rebooting, remove the Jumper before Default BIOS is recovered by reloading BIOS (for instance by using latest BIOS upgrade package from web product page).

Verify that Default BIOS has been recovered by making a successful reboot.



Warning: If the jumper (J41) is mounted and you make BIOS Upgrade etc. then the BIOS Recovery SPI Flash will be Upgraded and not the BIOS Default SPI Flash. This means that in case something goes wrong (power interruption or incorrect BIOS package used etc.) when Upgrading BIOS, then the BIOS Recovery SPI Flash might get corrupted.

6.15 SPI Connector (SPI) (J40)

The SPI Connector is normally not used. If however a SPI BIOS is connected via the SPI Connector then the board will try to boot on it.

Note	Pull U/D	Ioh/Iol	Type	Signal	PIN		Signal	Type	Ioh/Iol	Pull U/D	Note
	-			CLK	1	2	SB3V3	PWR	-	-	
	-		I	CS0#	3	4	ADDIN	IO		/10K	
	10K/		-	NC	5	6	NC	-	-	-	
	10K/		IO	MOSI	7	8	ISOLATE#	IO		/10K	
	-		IO	MISO	9	10	GND	PWR	-	-	

Signal	Description
CLK	Serial Clock
SB3V3	3.3V Standby Voltage power line. Normally output power, but when Motherboard is turned off then the on-board SPI Flash can be 3.3V power sourced via this pin.
CS0#	CS0# Chip Select 0, active low.
ADDIN	ADDIN input signal must be NC.
MOSI	Master Output, Slave Input
ISOLATE#	The ISOLATE# input, active low, is normally NC, but must be connected to GND when loading SPI flash. Power Supply to the Motherboard must be turned off when loading SPI flash. The pull up resistor is connected via diode to 5VSB.
MISO	Master Input, Slave Output

6.16 XDP-CPU (Debug Port for CPU) (J14)

The XDP-CPU (Intel Debug Port for CPU) connector is not mounted and not supported. XDP connector layout (pads) is located on the backside of PCB and is prepared for the Molex 52435-2671 (or 52435-2672).

Pin	Signal	Description	Type	Pull Up/Down	Note
1	OBSFN_A0				
2	OBSFN_A1				
3	GND		PWR	-	
4	NC		NC	-	
5	NC		NC	-	
6	GND		PWR	-	
7	NC		NC	-	
8	NC		NC	-	
9	GND		PWR	-	
10	HOOK0				
11	HOOK1				
12	HOOK2				
13	HOOK3				
14	HOOK4				
15	HOOK5				
16	+5V		PWR	-	
17	HOOK6				
18	HOOK7			500R	(500R by 2x1K in parallel)
19	GND		PWR	-	
20	TDO			/51R	
21	TRST#			/51R	
22	TDI			/51R	
23	TMS			/51R	
24	NC		NC	-	
25	GND		PWR	-	
26	TCK0			/51R	

6.17 XDP-PCH (Debug Port for Chipset) (J13)

The XDP-PCH (Intel Debug Port for Chipset) connector is not mounted and not supported. XDP-PCH connector layout (pads) is prepared for the Molex 52435-2671 (or 52435-2672).

Pin	Signal	Description	Type	Pull Up/Down	Note
1	NC		NC	-	
2	NC		NC	-	
3	GND		PWR	-	
4	NC		NC	-	
5	NC		NC	-	
6	GND		PWR	-	
7	NC		NC	-	
8	NC		NC	-	
9	GND		PWR	-	
10	HOOK0	RSMRST#			Connected to HOOK6
11	HOOK1	PWRBTN#			
12	HOOK2		NC	-	
13	HOOK3		NC	-	
14	HOOK4		NC	-	
15	HOOK5		NC	-	
16	+5V		PWR	-	
17	HOOK6				Connected to HOOK1
18	HOOK7	RESET#		500R	(500R by 2x1K in parallel)
19	GND		PWR	-	
20	TDO			210R/100R	
21	TRST#				
22	TDI			210R/100R	
23	TMS			210R/100R	
24	NC		NC	-	
25	GND		PWR	-	
26	TCK0			/51R	

7 Slot Connectors (PCIe, PCI)

7.1 PCIe Connectors

The KTQ67 support one (x16) (16-lane) PCI Express port and one x4 PCI Express port (in a x16 PCI Express connector).

The **16-lane (x16) PCI Express** (PCIe 2.0) port can be used for external PCI Express cards inclusive graphics card. It is located nearest the CPU. Maximum theoretical bandwidth using 16 lanes is 16 GB/s.

The **4-lane (x4) PCI Express** (PCIe 2.0) can be used for any PCIe1, PCIe2 or PCIe4 cards inclusive “Riser PCIe1 to PCI Dual flexible card”.

7.1.1 PCI-Express x16 Connector (PCIe x16)

Note	Type	Signal	PIN		Signal	Type	Note
		+12V	B1	A1	NC		
		+12V	B2	A2	+12V		
		+12V	B3	A3	+12V		
		GND	B4	A4	GND		
		SMB_CLK	B5	A5	NC		
		SMB_DATA	B6	A6	NC		
		GND	B7	A7	NC		
		+3V3	B8	A8	NC		
		NC	B9	A9	+3V3		
		SB3V3	B10	A10	+3V3		
		WAKE#	B11	A11	RST#		
		NC	B12	A12	GND		
		GND	B13	A13	PCIE_x16 CLK		
		PEG_TXP[0]	B14	A14	PCIE_x16 CLK#		
		PEG_TXN[0]	B15	A15	GND		
		GND	B16	A16	PEG_RXP[0]		
		CLKREQ	B17	A17	PEG_RXN[0]		
		GND	B18	A18	GND		
		PEG_TXP[1]	B19	A19	NC		
		PEG_TXN[1]	B20	A20	GND		
		GND	B21	A21	PEG_RXP[1]		
		GND	B22	A22	PEG_RXN[1]		
		PEG_TXP[2]	B23	A23	GND		
		PEG_TXN[2]	B24	A24	GND		
		GND	B25	A25	PEG_RXP[2]		
		GND	B26	A26	PEG_RXN[2]		
		PEG_TXP[3]	B27	A27	GND		
		PEG_TXN[3]	B28	A28	GND		
		GND	B29	A29	PEG_RXP[3]		
		NC	B30	A30	PEG_RXN[3]		
		CLKREQ	B31	A31	GND		
		GND	B32	A32	NC		
		PEG_TXP[4]	B33	A33	NC		
		PEG_TXN[4]	B34	A34	GND		
		GND	B35	A35	PEG_RXP[4]		

		GND	B36	A36	PEG_RXN[4]		
		PEG_TXP[5]	B37	A37	GND		
		PEG_TXN[5]	B38	A38	GND		
		GND	B39	A39	PEG_RXP[5]		
		GND	B40	A40	PEG_RXN[5]		
		PEG_TXP[6]	B41	A41	GND		
		PEG_TXN[6]	B42	A42	GND		
		GND	B43	A43	PEG_RXP[6]		
		GND	B44	A44	PEG_RXN[6]		
		PEG_TXP[7]	B45	A45	GND		
		PEG_TXN[7]	B46	A46	GND		
		GND	B47	A47	PEG_RXP[7]		
		CLKREQ	B48	A48	PEG_RXN[7]		
		GND	B49	A49	GND		
		PEG_TXP[8]	B50	A50	NC		
		PEG_TXN[8]	B51	A51	GND		
		GND	B52	A52	PEG_RXP[8]		
		GND	B53	A53	PEG_RXN[8]		
		PEG_TXP[9]	B54	A54	GND		
		PEG_TXN[9]	B55	A55	GND		
		GND	B56	A56	PEG_RXP[9]		
		GND	B57	A57	PEG_RXN[9]		
		PEG_TXP[10]	B58	A58	GND		
		PEG_TXN[10]	B59	A59	GND		
		GND	B60	A60	PEG_RXP[10]		
		GND	B61	A61	PEG_RXN[10]		
		PEG_TXP[11]	B62	A62	GND		
		PEG_TXN[11]	B63	A63	GND		
		GND	B64	A64	PEG_RXP[11]		
		GND	B65	A65	PEG_RXN[11]		
		PEG_TXP[12]	B66	A66	GND		
		PEG_TXN[12]	B67	A67	GND		
		GND	B68	A68	PEG_RXP[12]		
		GND	B69	A69	PEG_RXN[12]		
		PEG_TXP[13]	B70	A70	GND		
		PEG_TXN[13]	B71	A71	GND		
		GND	B72	A72	PEG_RXP[13]		
		GND	B73	A73	PEG_RXN[13]		
		PEG_TXP[14]	B74	A74	GND		
		PEG_TXN[14]	B75	A75	GND		
		GND	B76	A76	PEG_RXP[14]		
		GND	B77	A77	PEG_RXN[14]		
		PEG_TXP[15]	B78	A78	GND		
		PEG_TXN[15]	B79	A79	GND		
		GND	B80	A80	PEG_RXP[15]		
		CLKREQ	B81	A81	PEG_RXN[15]		
		NC	B82	A82	GND		

7.1.3 PCI-Express x4 Connector (PCIe x4) (J33)

The KTQ67 support one PCIe x4 in a PCIe x16 slot. All GND pins in the PCIe x16 connector are connected to GND, but all signal pins from pin 33 and above are all unconnected.

Note	Type	Signal	PIN		Signal	Type	Note
		+12V	B1	A1	NC		
		+12V	B2	A2	+12V		
		+12V	B3	A3	+12V		
		GND	B4	A4	GND		
		SMB_CLK	B5	A5	NC		
		SMB_DATA	B6	A6	NC		
		GND	B7	A7	NC		
		+3V3	B8	A8	NC		
		NC	B9	A9	+3V3		
		SB3V3	B10	A10	+3V3		
		WAKE#	B11	A11	RST#		
		NC	B12	A12	GND		
		GND	B13	A13	PCIE_x16 CLK		
		PEG_TXP[0]	B14	A14	PCIE_x16 CLK#		
		PEG_TXN[0]	B15	A15	GND		
		GND	B16	A16	PEG_RXP[0]		
1		CLKREQ	B17	A17	PEG_RXN[0]		
		GND	B18	A18	GND		
		PEG_TXP[1]	B19	A19	NC		
		PEG_TXN[1]	B20	A20	GND		
		GND	B21	A21	PEG_RXP[1]		
		GND	B22	A22	PEG_RXN[1]		
		PEG_TXP[2]	B23	A23	GND		
		PEG_TXN[2]	B24	A24	GND		
		GND	B25	A25	PEG_RXP[2]		
		GND	B26	A26	PEG_RXN[2]		
		PEG_TXP[3]	B27	A27	GND		
		PEG_TXN[3]	B28	A28	GND		
		GND	B29	A29	PEG_RXP[3]		
		NC	B30	A30	PEG_RXN[3]		
		NC	B31	A31	GND		
		GND	B32	A32	NC		

Note 1: 10K ohm pull-up to 3V3 Dual.

7.2 PCI Slot Connectors

KTQ67/Flex-Medical support 2 PCI slots PCI0 – PCI1 (J1 – J2).

Note	Type	Signal	Terminal S	Terminal C	Signal	Type	Note	
	PWR	-12V	F01	E01	TRST#	O		
	O	TCK	F02	E02	+12V	PWR		
	PWR	GND	F03	E03	TMS	O		
NC	I	TDO	F04	E04	TDI	O		
	PWR	+5V	F05	E05	+5V	PWR		
	PWR	+5V	F06	E06	INTA#	I		
	I	INTB#	F07	E07	INTC#	I		
	I	INTD#	F08	E08	+5V	PWR		
NC	-	-	F09	E09	-	-	NC	
NC	-	-	F10	E10	+5V (I/O)	PWR		
NC	-	-	F11	E11	-	-	NC	
	PWR	GND	F12	E12	GND	PWR		
	PWR	GND	F13	E13	GND	PWR		
NC	-	-	F14	E14	GNT3#	OT		
	PWR	GND	F15	E15	RST#	O		
	O	CLKB	F16	E16	+5V (I/O)	PWR		
	PWR	GND	F17	E17	GNT0#	OT		
	I	REQ0#	F18	E18	GND	PWR		
	PWR	+5V (I/O)	F19	E19	PME#	I		
	IOT	AD31	F20	E20	AD30	IOT		
	IOT	AD29	F21	E21	+3.3V	PWR		
	PWR	GND	F22	E22	AD28	IOT		
	IOT	AD27	F23	E23	AD26	IOT		
	IOT	AD25	F24	E24	GND	PWR		
	PWR	+3.3V	F25	E25	AD24	IOT		
	IOT	C/BE3#	F26	E26	GNT1#	OT		
	IOT	AD23	F27	E27	+3.3V	PWR		
	PWR	GND	F28	E28	AD22	IOT		
	IOT	AD21	F29	E29	AD20	IOT		
	IOT	AD19	F30	E30	GND	PWR		
	PWR	+3.3V	F31	E31	AD18	IOT		
	IOT	AD17	F32	E32	AD16	IOT		
	IOT	C/BE2#	F33	E33	+3.3V	PWR		
	PWR	GND	F34	E34	FRAME#	IOT		
	IOT	IRDY#	F35	E35	GND	PWR		
	PWR	+3.3V	F36	E36	TRDY#	IOT		
	IOT	DEVSEL#	F37	E37	GND	PWR		
	PWR	GND	F38	E38	STOP#	IOT		
	IOT	LOCK#	F39	E39	+3.3V	PWR		
	IOT	PERR#	F40	E40	SDONE	IO		
	PWR	+3.3V	F41	E41	SB0#	IO		
	IOC	SERR#	F42	E42	GND	PWR		
	PWR	+3.3V	F43	E43	PAR	IOT		
	IOT	C/BE1#	F44	E44	AD15	IOT		
	IOT	AD14	F45	E45	+3.3V	PWR		
	PWR	GND	F46	E46	AD13	IOT		
	IOT	AD12	F47	E47	AD11	IOT		
	IOT	AD10	F48	E48	GND	PWR		
	PWR	GND	F49	E49	AD09	IOT		
SOLDER SIDE					COMPONENT SIDE			
	IOT	AD08	F52	E52	C/BE0#	IOT		
	IOT	AD07	F53	E53	+3.3V	PWR		
	PWR	+3.3V	F54	E54	AD06	IOT		
	IOT	AD05	F55	E55	AD04	IOT		
	IOT	AD03	F56	E56	GND	PWR		
	PWR	GND	F57	E57	AD02	IOT		
	IOT	AD01	F58	E58	AD00	IOT		
	PWR	+5V (I/O)	F59	E59	+5V (I/O)	PWR		
	IOT	ACK64#	F60	E60	REQ64#	IOT		
	PWR	+5V	F61	E61	+5V	PWR		
	PWR	+5V	F62	E62	+5V	PWR		

7.2.1 Signal Description – PCI Slot Connector

SYSTEM PINS	
CLK	Clock provides timing for all transactions on PCI and is an input to every PCI device. All other PCI signals, except RST#, INTA#, INTB#, INTC#, and INTD#, are sampled on the rising edge of CLK and all other timing parameters are defined with respect to this edge. PCI operates at 33MHz.
PME#	Power Management Event interrupt signal. Wake up signal.
RST#	Reset is used to bring PCI-specific registers, sequencers, and signals to a consistent state. What effect RST# has on a device beyond the PCI sequencer is beyond the scope of this specification, except for reset states of required PCI configuration registers. Anytime RST# is asserted, all PCI output signals must be driven to their benign state. In general, this means they must be asynchronously tri-stated. SERR# (open drain) is floated. REQ# and GNT# must both be tri-stated (they cannot be driven low or high during reset). To prevent AD, C/BE#, and PAR signals from floating during reset, the central resource may drive these lines during reset (bus parking) but only to a logic low level—they may not be driven high. RST# may be asynchronous to CLK when asserted or deasserted. Although asynchronous, deassertion is guaranteed to be a clean, bounce-free edge. Except for configuration accesses, only devices that are required to boot the system will respond after reset.
ADDRESS AND DATA	
AD[31::00]	Address and Data are multiplexed on the same PCI pins. A bus transaction consists of an address phase followed by one or more data phases. PCI supports both read and write bursts. The address phase is the clock cycle in which FRAME# is asserted. During the address phase AD[31::00] contain a physical address (32 bits). For I/O, this is a byte address; for configuration and memory, it is a DWORD address. During data phases AD[07::00] contain the least significant byte (lsb) and AD[31::24] contain the most significant byte (msb). Write data is stable and valid when IRDY# is asserted and read data is stable and valid when TRDY# is asserted. Data is transferred during those clocks where both IRDY# and TRDY# are asserted.
C/BE[3::0]#	Bus Command and Byte Enables are multiplexed on the same PCI pins. During the address phase of a transaction, C/BE[3::0]# define the bus command. During the data phase C/BE[3::0]# are used as Byte Enables. The Byte Enables are valid for the entire data phase and determine which byte lanes carry meaningful data. C/BE[0]# applies to byte 0 (lsb) and C/BE[3]# applies to byte 3 (msb).
PAR	Parity is even parity across AD[31::00] and C/BE[3::0]#. Parity generation is required by all PCI agents. PAR is stable and valid one clock after the address phase. For data phases, PAR is stable and valid one clock after either IRDY# is asserted on a write transaction or TRDY# is asserted on a read transaction. Once PAR is valid, it remains valid until one clock after the completion of the current data phase. (PAR has the same timing as AD[31::00], but it is delayed by one clock.) The master drives PAR for address and write data phases; the target drives PAR for read data phases.
INTERFACE CONTROL PINS	
FRAME#	Cycle Frame is driven by the current master to indicate the beginning and duration of an access. FRAME# is asserted to indicate a bus transaction is beginning. While FRAME# is asserted, data transfers continue. When FRAME# is deasserted, the transaction is in the final data phase or has completed.
IRDY#	Initiator Ready indicates the initiating agent's (bus master's) ability to complete the current data phase of the transaction. IRDY# is used in conjunction with TRDY#. A data phase is completed on any clock both IRDY# and TRDY# are sampled asserted. During a write, IRDY# indicates that valid data is present on AD[31::00]. During a read, it indicates the master is prepared to accept data. Wait cycles are inserted until both IRDY# and TRDY# are asserted together.
TRDY#	Target Ready indicates the target agent's (selected device's) ability to complete the current data phase of the transaction. TRDY# is used in conjunction with IRDY#. A data phase is completed on any clock both TRDY# and IRDY# are sampled asserted. During a read, TRDY# indicates that valid data is present on AD[31::00]. During a write, it indicates the target is prepared to accept data. Wait cycles are inserted until both IRDY# and TRDY# are asserted together.
STOP#	Stop indicates the current target is requesting the master to stop the current transaction.
LOCK#	Lock indicates an atomic operation that may require multiple transactions to complete. When LOCK# is asserted, non-exclusive transactions may proceed to an address that is not currently locked. A grant to start a transaction on PCI does not guarantee control of LOCK#. Control of LOCK# is obtained under its own protocol in conjunction with GNT#. It is possible for different agents to use PCI while a single master retains ownership of LOCK#. If a device implements Executable Memory, it should also implement LOCK# and guarantee complete access exclusion in that memory. A target of an access that supports LOCK# must provide exclusion to a minimum of 16 bytes (aligned). Host bridges that have system memory behind them should implement LOCK# as a target from the PCI bus point of view and optionally as a master.
IDSEL	Initialization Device Select is used as a chip select during configuration read and write transactions.
DEVSEL#	Device Select, when actively driven, indicates the driving device has decoded its address as the target of the current access. As an input, DEVSEL# indicates whether any device on the bus has been selected.

ARBITRATION PINS (BUS MASTERS ONLY)

REQ#	Request indicates to the arbiter that this agent desires use of the bus. This is a point to point signal. Every master has its own REQ# which must be tri-stated while RST# is asserted.
GNT#	Grant indicates to the agent that access to the bus has been granted. This is a point to point signal. Every master has its own GNT# which must be ignored while RST# is asserted. While RST# is asserted, the arbiter must ignore all REQ# lines since they are tri-stated and do not contain a valid request. The arbiter can only perform arbitration after RST# is deasserted. A master must ignore its GNT# while RST# is asserted. REQ# and GNT# are tri-state signals due to power sequencing requirements when 3.3V or 5.0V only add-in boards are used with add-in boards that use a universal I/O buffer.

ERROR REPORTING PINS.

The error reporting pins are required by all devices and maybe asserted when enabled

PERR#	Parity Error is only for the reporting of data parity errors during all PCI transactions except a Special Cycle. The PERR# pin is sustained tri-state and must be driven active by the agent receiving data two clocks following the data when a data parity error is detected. The minimum duration of PERR# is one clock for each data phase that a data parity error is detected. (If sequential data phases each have a data parity error, the PERR# signal will be asserted for more than a single clock.) PERR# must be driven high for one clock before being tri-stated as with all sustained tri-state signals. There are no special conditions when a data parity error may be lost or when reporting of an error may be delayed. An agent cannot report a PERR# until it has claimed the access by asserting DEVSEL# (for a target) and completed a data phase or is the master of the current transaction.
SERR#	System Error is for reporting address parity errors, data parity errors on the Special Cycle command, or any other system error where the result will be catastrophic. If an agent does not want a non-maskable interrupt (NMI) to be generated, a different reporting mechanism is required. SERR# is pure open drain and is actively driven for a single PCI clock by the agent reporting the error. The assertion of SERR# is synchronous to the clock and meets the setup and hold times of all bused signals. However, the restoring of SERR# to the deasserted state is accomplished by a weak pullup (same value as used for s/t/s) which is provided by the system designer and not by the 55signaling agent or central resource. This pull-up may take two to three clock periods to fully restore SERR#. The agent that reports SERR#s to the operating system does so anytime SERR# is sampled asserted.

INTERRUPT PINS (OPTIONAL).

Interrupts on PCI are optional and defined as "level sensitive," asserted low (negative true), using open drain output drivers. The assertion and deassertion of INTx# is asynchronous to CLK. A device asserts its INTx# line when requesting attention from its device driver. Once the INTx# signal is asserted, it remains asserted until the device driver clears the pending request. When the request is cleared, the device deasserts its INTx# signal. PCI defines one interrupt line for a single function device and up to four interrupt lines for a multi-function device or connector. For a single function device, only INTA# may be used while the other three interrupt lines have no meaning.

INTA#	Interrupt A is used to request an interrupt.
INTB#	Interrupt B is used to request an interrupt and only has meaning on a multi-function device.
INTC#	Interrupt C is used to request an interrupt and only has meaning on a multi-function device.
INTD#	Interrupt D is used to request an interrupt and only has meaning on a multi-function device.

7.2.2 KTQ67 PCI IRQ & INT routing

Board type	Slot	REQ	GNT	IDSEL	INTA	INTB	INTC	INTD
KTQ67/Flex-Medical	0	REQ0	GNT0	17	INTA	INTB	INTC	INTD
	1	REQ1	GNT1	18	INTF	INTG	INTH	INTE

When using the 820982 "PCI Riser - Flex - 2slot w. arbiter" the lower slot has IDSEL / IRQs routed straight through and the top slot has the routing: IDSEL=AD22, INT_PIRQ#D, INT_PIRQ#A, INT_PIRQ#B, INT_PIRQ#C. 820982 PCI Riser shall be plugged into Slot 0 and jumper in AD30.

8 On-board - & mating connector types

The Mating connectors / Cables are connectors or cable kits which are fitting the On-board connector. The highlighted cable kits (in **bold**) are included in the "KTQ67 Cable & Driver Kit" PN 826599, in different quantities depending on type of connector. For example there are 4x 821017 COM cables and 6x 821035 SATA cables.

Connector	On-board Connectors		Mating Connectors / Cables	
	Manufacturer	Type no.	Manufacturer	Type no.
FAN_CPU	Foxconn	HF2704E-M1	AMP	1375820-4 (4-pole)
FAN_SYS	AMP	1470947-1	AMP	1375820-3 (3-pole)
KBDMSE	Molex	22-23-2061	Molex	22-01-2065
			Kontron	KT 1046-3381
CDROM	Foxconn	HF1104E	Molex	50-57-9404
	Molex	70543-0038		
SATA	Hon Hai	LD1807V-S52T	Molex	67489-8005
			Kontron	KT 821035 (cable kit)
ATXEWR	Molex	44206-0002	Molex	5557-24R
ATX+12V-4pin	Lotes	ABA-POW-003-K02	Molex	39-01-2045
EDP	Tyco	5-2069716-3	Tyco	2023344-3
LVDS	Don Connex	C44-40BSB1-G	Don Connex	A32-40-C-G-B-1
			Kontron	KT 910000005
			Kontron	KT 821515 (cable kit)
			Kontron	KT 821155 (cable kit)
COM1,2, 3, 4	Wuerth	61201020621	Molex	90635-1103
			Kontron	KT 821016 (cable kit)
			Kontron	KT 821017 (cable kit)
USB6/8/9, 10/11, 12/13	Pinrex	512-90- 10GBB2	Kontron	KT 821401 (cable kit)
USB6/7 (*)	(FRONTPNL)	-	Kontron	KT 821401 (cable kit)
AUDIO_HEAD	Molex	87831-2620	Molex	51110-2651
			Kontron	KT 821043 (cable kit)
FRONTPNL	Pinrex	512-90-24GBB3	Molex	90635-1243
			Kontron	KT 821042 (cable kit)
FEATURE	Foxconn	HS5422F	Don Connex	A05c-44-B-G-A-1-G
				KT 1052-5885 (cable kit)

* USB6/USB7 is located in FRONTPNL connector. Depending on application KT 821401 can be used.

Note: Only one connector will be mentioned for each type of on-board connector even though several types with same fit, form and function are approved and could be used as alternative. Please also notice that standard connectors like DVI, PCIe, PCI, Ethernet and USB are not included in the list.

9 System Resources

9.1 Memory Map

Address (hex)		Size (hex)	Description
0xFF000000	0xFFFFFFFF	1000000	Motherboard resources
0xFEE10000	0xFEFFFFFF	1F0000	PCI bus
0xFEE00000	0xFEE0FFFF	10000	Motherboard resources
0xFED94000	0xFED9FFFF	6C000	PCI bus
0xFED90000	0xFED93FFF	4000	Motherboard resources
0xFED40000	0xFED8FFFF	50000	PCI bus
0xFED20000	0xFED3FFFF	20000	Motherboard resources
0xFED1C000	0xFED1FFFF	4000	Motherboard resources
0xFED1A000	0xFED1BFFF	2000	PCI bus
0xFED10000	0xFED19FFF	A000	Motherboard resources
0xFED09000	0xFED0FFFF	7000	PCI bus
0xFED08000	0xFED08FFF	1000	Motherboard resources
0xFED00400	0xFED07FFF	7BFF	PCI bus
0xFED00000	0xFED003FF	400	High Precision Event Timer
0xFEC00000	0xFECFFFFFF	100000	Motherboard resources
0xFE52A010	0xFEBFFFFFF	6D5FF0	PCI bus
0xFE52A000	0xFE52A00F	10	Intel® Management Engine Interface
0xFE529000	0xFE529FFF	1000	Intel® AMT - SOL (COM5)
0xFE528000	0xFE528FFF	1000	Intel® 82579LM Gigabit Network
0xFE527400	0xFE527FFF	C00	PCI bus
0xFE527000	0xFE5273FF	400	Intel® Chipset USB EHCI - 1C2D
0xFE526400	0xFE526FFF	C00	PCI bus
0xFE526000	0xFE5263FF	400	Intel® Chipset USB EHCI - 1C26
0xFE525800	0xFE525FFF	800	PCI bus
0xFE525000	0xFE5257FF	800	Intel® Chipset 6 port SATA ACHI - 1C02
0xFE524100	0xFE524FFF	F00	PCI bus
0xFE524000	0xFE5240FF	100	Intel® Chipset SMBus Controller - 1C22
0xFE520000	0xFE523FFF	4000	High Definition Audio Controller
0xFE500000	0xFE51FFFF	20000	Intel® 82579LM Gigabit Network
0xFE400000	0xFE4FFFFFF	100000	Intel® Chipset PCIe Root port 1 - 1C26 LAN controller
0xFE000000	0xFE3FFFFFF	400000	Video Controller
0xF0000000	0xFDFFFFFF	E000000	PCI bus
0xE0000000	0xEFFFFFFF	10000000	Motherboard resources
0xD0000000	0xDFFFFFFF	10000000	Video Controller
0xBF000000	0xCFFFFFFF	10600000	PCI bus
0xC00000	0xDFFFFF	20000	PCI bus
0xA00000	0xBFFFFF	20000	VgaSave PCI bus

9.2 PCI Devices

Bus #	Device #	Function #	Vendor ID	Device ID	Chip	Device Function
0	0	0	8086	0100	CPU	Intel – DRAM Controller
0	2	0	8086	0102	CPU	Intel - VGA Controller
0	22	0	8086	1C3A	Q67 Chipset	Intel – Management Engine
0	25	0	8086	1502	82579LM LAN	Intel - Ethernet Controller
0	26	0	8086	1C2D	Q67 Chipset	Intel - USB
0	27	0	8086	0403	Q67 Chipset	Intel - HD Audio
0	28	0	8086	1C10	Q67 Chipset	Intel – PCIe Root Port 1
0	29	0	8086	1C26	Q67 Chipset	Intel - USB
0	30	0	8086	244E	82801 PCI Bridge	Intel – PCI Bridge
0	31	0	8086	1C4E	Q67 Chipset	Intel - LPC
0	31	2	8086	1C03	Q67 Chipset	Intel - SATA AHCI Controller
0	31	3	8086	1C22	Q67 Chipset	Intel - SMBus
1	0	0	8086	10D3	82574L LAN	Intel - Ethernet Controller

9.4 IO Map

Address range (hex)		Size (hex)	Description
0x0000F130	0x0000F137	8	Standard Dual Channel IDE Controller
0x0000F120	0x0000F123	4	Standard Dual Channel IDE Controller
0x0000F110	0x0000F117	8	Standard Dual Channel IDE Controller
0x0000F100	0x0000F103	4	Standard Dual Channel IDE Controller
0x0000F0F0	0x0000F0FF	10	Standard Dual Channel IDE Controller
0x0000F0E0	0x0000F0E7	8	Intel® AMT - SOL (COM5)
0x0000F0D0	0x0000F0D7	8	Intel® 6 port SATA AHCI - 1C03
0x0000F0C0	0x0000F0C3	4	Intel® 6 port SATA AHCI - 1C03
0x0000F0B0	0x0000F0B7	8	Intel® 6 port SATA AHCI - 1C03
0x0000F0A0	0x0000F0A3	4	Intel® 6 port SATA AHCI - 1C03
0x0000F060	0x0000F07F	20	Intel® 6 port SATA AHCI - 1C03
0x0000F040	0x0000F05F	20	Intel® SMBus - 1C22
0x0000F000	0x0000F03F	40	Intel® HD Graphics family
0x0000E000	0x0000EFFF	1000	Intel® 82574L LAN, C1e Root port 4 - 1C10
0x00001180	0x0000119F	20	Motherboard resources
0x00000D00	0x0000FFFF	F300	PCI bus
0x00000A00	0x00000A2F	30	Motherboard resources
0x00000500	0x0000057F	80	Motherboard resources
0x000004D0	0x000004D1	2	Programmable interrupt controller
0x00000400	0x0000047F	80	Motherboard resources
0x000003F8	0x000003FF	8	COM1
0x000003E8	0x000003EF	8	COM4
0x000003C0	0x000003DF	20	Intel® HD Graphics family
0x000003B0	0x000003BB	C	Intel® HD Graphics family
0x000002F8	0x000002FF	8	COM2
0x000002E8	0x000002EF	8	COM3
0x00000290	0x0000029F	10	Motherboard resources
0x0000020E	0x0000020F	2	Motherboard resources
0x000000F0	0x000000FF	10	Numeric data processor
0x000000E0	0x000000EF	10	Motherboard resources
0x000000D0	0x000000DF	10	Direct memory access controller
0x000000A2	0x000000BF	1E	Motherboard resources
0x000000A0	0x000000A1	2	Programmable interrupt controller
0x00000090	0x0000009F	10	Motherboard resources
0x0000008F	0x0000008F	1	Direct memory access controller
0x0000008C	0x0000008E	3	Motherboard resources
0x00000089	0x0000008B	3	Direct memory access controller
0x00000088	0x00000088	1	Motherboard resources
0x00000087	0x00000087	1	Direct memory access controller
0x00000084	0x00000086	3	Motherboard resources
0x00000081	0x00000083	3	Direct memory access controller
0x00000072	0x00000080	F	Motherboard resources
0x00000070	0x00000071	2	System CMOS/real time clock
0x00000065	0x0000006F	B	Motherboard resources
0x00000064	0x00000064	1	Standard PS/2 Keyboard
0x00000062	0x00000063	2	Motherboard resources
0x00000061	0x00000061	1	System Speaker
0x00000060	0x00000060	1	Standard PS/2 Keyboard
0x00000044	0x0000005F	1C	Motherboard resources
0x00000040	0x00000043	4	System Timer
0x00000022	0x0000003F	1E	Motherboard resources
0x00000020	0x00000021	2	Programmable interrupt controller
0x00000010	0x0000001F	10	Motherboard resources
0x00000000	0x0000000F	10	Direct memory access controller

10 BIOS

The BIOS Setup is used to view and configure BIOS settings for the board. The BIOS Setup is accessed by pressing the -key after the Power-On Self-Test (POST) memory test begins and before the operating system boot begins.

The BIOS settings will be loaded automatically when loading “Restore Default” see “Save & Exit” menu. In this Users Guide the default settings are indicated by **bold**. Please notice that “Restore User Defaults” might have different set of default values.

10.1 Main

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Main | Advanced | Chipset | Boot | Security | Save & Exit

BIOS Information		Choose the system default language.
BIOS Vendor	American Megatrends	
Core Version	4.6.5.4	
Compliancy	UEFI 2.3.1; PI 1.2	
BIOS Version	29	
Build Date and Time	01/07/2014 13:58:49	
EC Firmware Version	V0.19 03/31/13	
Board Information		
Product Name	KTQ67/FLEX-Medical	
PCB ID	03	
Serial #	01170492	
Part #	64620000	
Boot Count	18	
System Language	[English]	→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
System Date	[Wed 01/08/2014]	
System Time	[14:29:25]	
Access Level	Administrator	


Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Blue text for settings that can be changed. White text for actual setting to be changed via the control keys (Black text for settings that cannot be changed via control keys)

The following table describes the changeable settings:

Feature	Options	Description
System Date	MM/DD/YYYY	Set the system date.
System Time	HH:MM:SS	Set the system time.

10.2 Advanced



The Advanced (main) menu contains submenu selections which will be described in more details on the following pages.

In order to make a selection of a submenu activated the ↑↓ keys until the requested submenu becomes white color, then activate the <Enter>.

10.2.1 Advanced - PCI Subsystem Settings

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Advanced

PCI Bus Driver Version	V 2.05.02	Enables or Disables 64 bit capable Devices to be Decoded in Above 4G Address Space (Only if System Supports 64 bit PCI Decoding).
PCI 64bit Resources Handling Above 4G Decoding	[Disabled]	
PCI Common Settings		→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
PCI Latency Timer [32 PCI Bus Clocks] VGA Palette Snoop [Disabled] PERR# Generation [Disabled] SERR# Generation [Disabled]		
▶ PCI Express Settings		
▶ PCI Express GEN 2 Settings		

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
Above 4G Decoding	Disabled Enabled	Enables or Disables 64 bit capable Devices to be Decoded in Above 4G Address Space (Only if System Supports 64 bit PCI Decoding).
PCI Latency Timer	32 PCI Bus Clocks 64 PCI Bus Clocks 96 PCI Bus Clocks 128 PCI Bus Clocks 160 PCI Bus Clocks 192 PCI Bus Clocks 224 PCI Bus Clocks 248 PCI Bus Clocks	Value to be programmed into PCI Latency Timer Register.
VGA Palette Snoop	Disabled Enabled	Enables or Disables VGA Palette Registers Snooping.
PERR# Generation	Disabled Enabled	Enables or Disables PCI Device to Generate PERR#.
SERR# Generation	Disabled Enabled	Enables or Disables PCI Device to Generate SERR#.

PCI Express Settings

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.		
Advanced		
<p>PCI Express Device Register Settings Relaxed Ordering [Disabled] Extended Tag [Disabled] No Snoop [Enabled] Maximum Payload [Auto] Maximum Read Request [Auto]</p> <p>PCI Express Link Register Settings ASPM Support [Disabled] WARNING: Enabling ASPM may cause Some PCI-E devices to fail Extended Synch [Disabled]</p> <p>Link Training Retry [5] Link Training Timeout (uS) 100 Unpopulated Links [Keep Link ON] Restore PCIe Registers [Disabled]</p>	<p>Enables or Disables PCI Express Device Relaxed Ordering.</p>	<p>→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</p>
Version 2.15.1236. Copyright © 2012 American Megatrends, Inc		

Function	Selection	Description
Relaxed Ordering	Disabled Enabled	Enables or Disables PCI Express Device Relaxed Ordering.
Extended Tag	Disabled Enabled	If ENABLED allows Device to use 8-bit Tag field as a requester.
No Snoop	Disabled Enabled	Enables or Disables PCI Express Device No Snoop option.
Maximum Payload	Auto 128 Bytes 256 Bytes 512 Bytes 1024 Bytes 2048 Bytes 4096 Bytes	Set Maximum Payload of PCI Express Device or allow System BIOS to select the value.
Maximum Read Request	Auto 128 Bytes 256 Bytes 512 Bytes 1024 Bytes 2048 Bytes 4096 Bytes	Set Maximum Read Request Size of PCI Express Device or allow System BIOS to select the value.
ASPM Support	Disabled Auto Force L0s	Set the ASPM Level: Force L0s - Force all links to L0s State: Auto – BIOS auto configure: Disable – Disabled ASPM
Extended Synch	Disabled Enabled	If ENABLED allows generation of Extended Synchronization patterns.
Link Training Retry	Disabled 2 3 5	Defines number of Retry Attempts software will take to retrain the link if previous training attempt was unsuccessful.
Link Training Timeout (uS)	100 (note1)	Defines number of Microseconds software will wait before polling 'Link Training' bit in Link Status register. Value range from 1 to 100uS.
Unpopulated Links	Keep Link ON Disable Link	In order to save power, software will disable unpopulated PCI Express links, if this option set to 'Disabled Link'.
Restore PCIe Registers	Enabled Disabled	On non-PCI Express aware OS's (Pre Windows Vista) some devices may not be correctly reinitialized after S3. Enabling this restores PCI Express device configurations on S3 resume. Warning: Enabling this may cause issues with other hardware after S3 resume.

Note1: Use either digit keys to enter value or +/- keys to increase/decrease value. Don't use mix of digit keys and +/- keys.

PCI Express GEN 2 Settings

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.		
Advanced		
<p>PCI Express GEN2 Device Register Settings</p> <p>Completion Timeout [Default] ARI Forwarding [Disabled] AtomicOp Requester Enable [Disabled] AtomicOp Egress Blocking [Disabled] IDO Request Enable [Disabled] IDO Completion Enable [Disabled] LTR Mechanism Enable [Disabled] End-End TLP Prefix Blocking [Disabled]</p> <p>PCI Express GEN2 Link Register Settings</p> <p>Target Link Speed [Auto] Clock Power Management [Disabled] Compliance SOS [Disabled] Hardware Autonomous Width [Enabled] Hardware Autonomous Speed [Enabled]</p>		<p>In device Functions that support Completion Timeout programmability, modify the Completion Timeout value is allowed. Default: 50us to 50ms. Shorter: shorter timeout ranges supported by hardware. Longer: software will use longer timeout ranges.</p> <p>→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</p>
Version 2.15.1236. Copyright © 2012 American Megatrends, Inc		

Function	Selection	Description
Completion Timeout	Default Shorter Longer Disabled	In device Functions that support Completion Timeout programmability, modify the Completion Timeout range value is allowed. Default: 50us to 50ms. Shorter: shorter ranges supported by HW. Longer: longer ranges implemented by SW.
ARI Forwarding	Disabled Enabled	If supported by HW and Enabled, the Downstream Port disables its traditional Device Number field being 0 enforcement when turning a Type1 Configuration Request into a Type0 Configuration Request, permitting access to Extended Functions in an ARI Device immediately below the port.
AtomicOp Requester Enable	Disabled Enabled	If supported by HW and Enabled, initiate AtomicOp Requests only if Bus Master Enable bit is in the Command Register Set.
AtomicOp Egress Blocking	Disabled Enabled	If supported by HW and Enabled, outbound AtomicOp Requests via Egress Ports will be blocked.
IDO Request Enable	Disabled Enabled	If supported by HW and Enabled, permit setting the number of ID-Based Ordering (IDO) bit (Attribute[2]) requests to be initiated.
IDO Completion Enable	Disabled Enabled	If supported by HW and Enabled, permit setting the number of ID-Based Ordering (IDO) bit (Attribute[2]) requests to be initiated.
LTR Mechanism Enable	Disabled Enabled	If supported by HW and Enabled, enable the Latency Tolerance Reporting (LTR) Mechanism.
End-End TLP Prefix Blocking	Disabled Enabled	If supported by HW and Enabled, block forwarding of TLPs containing End-End TLP Prefixes.
Target Link Speed	Auto Force to 2.5 GT/s Force to 5.0 GT/s	If supported by HW and set to 'Force to 2.5 GT/s' for Downstream Ports, this sets an upper limit on link operational speed by restricting the values advertised by the Upstream component in its training sequences. When 'Auto' is selected HW initialized data will be used.
Clock Power Management	Disabled Enabled	If supported by HW and Enabled, device is permitted to use CLKREQ# signal for power management of Link clock in accordance to protocol defined in appropriate form factor specification.
Compliance SOS	Disabled Enabled	If supported by HW and Enabled, force LTSSM to send SKP Ordered Sets between sequences when sending Compliance Pattern or Modified Compliance Pattern.
Hardware Autonomous Width	Enabled Disabled	If supported by HW and Disabled, disable the HW ability to change link width except width size reduction for the purpose of correcting unstable link operation.
Hardware Autonomous Speed	Enabled Disabled	If supported by HW and Disabled, disable the HW ability to change link speed except speed rate reduction for the purpose of correcting unstable link operation.

10.2.2 Advanced - APCI Settings

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Advanced

ACPI Settings		Enables or Disables BIOS APCI Auto Configuration.
Enable ACPI Auto Configuration	[Disabled]	
Enable Hibernation	[Enabled]	
ACPI Sleep State	[Both S1 and S3 avai...]	
Lock Legacy Resources	[Disabled]	
S3 Video Repost	[Disabled]	

→← : Select Screen
 ↑↓ : Select Item
 Enter: Select
 +/- : Change Opt.
 F1: General Help
 F2: Previous Values
 F3: Optimized Defaults
 F4: Save & Exit
 ESC: Exit

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
Enable ACPI Auto Configuration	Disabled Enabled	Enables or Disables BIOS APCI Auto Configuration.
Enable Hibernation	Disabled Enabled	Enables or Disables System ability to Hibernate (OS/S4 Sleep State). This option may be not effective with some OS.
ACPI Sleep State	Suspend Disabled S1 only(CPU Stop Clock) S3 only (Suspend to RAM) Both S1 and S3 available...	Select the highest ACPI sleep state the system will enter when the SUSPEND button is pressed.
Lock Legacy Resources	Disabled Enabled	Enables or Disables Lock of Legacy Resources.
S3 Video Repost	Disabled Enabled	Enables or Disables S3 Video Repost.

10.2.3 Advanced - Trusted Computing

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Advanced

<p>TPM Configuration</p> <p>TPM Support [Enable]</p> <p>TPM State [Disabled]</p> <p>Pending TPM operation [None]</p> <p>Current TPM Status Information</p> <p>TPM Enabled Status: [Disabled]</p> <p>TPM Active Status: [Deactivated]</p> <p>TPM Owner Status: [UnOwned]</p>	<p>Enables or Disables BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1A interface will not be available.</p> <p>→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</p>
---	---

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
TPM Support	Disabled Enabled	Enables or Disables BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1A interface will not be available.
TPM State	Disabled Enabled	Turn TPM Enable/Disable. NOTE: Your Computer will reboot during restart in order to change State of TPM.
Pending operation	None Enable Take Ownership Disable Take Ownership TPM Clear	Schedule an Operation for the Security Device. NOTE: Your Computer will reboot during restart in order to change State of the Device.

10.2.4 Advanced - CPU Configuration

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Advanced

CPU Configuration		<p>Enabled for Windows XP and Linux (OS optimized for Hyper-Threading Technology) and Disabled for other OS (OS not optimized for Hyper-Threading Technology). When Disabled only one thread per enabled core is enabled.</p> <p>→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</p>
Intel® Pentium® CPU G850 @	2.90GHz	
CPU Signature	206a7	
Microcode Patch	28	
Max CPU Speed	2900 MHz	
Min CPU Speed	1600 MHz	
CPU Speed	2900 MHz	
Processor Cores	2	
Intel HT Technology	Not Supported	
Intel VT-x Technology	Supported	
Intel SMX Technology	Not Supported	
64-bit	Supported	
L1 Data Cache	32 kB x 2	
L1 Code Cache	32 kB x 2	
L2 Cache	256 kB x 2	
L3 Cache	3072 kB	
Hyper-threading	[Enabled]	
Active Processor Cores	[All]	
Limit CPUID Maximum	[Disabled]	
Execute Disable Bit	[Enabled]	
Intel Virtualization Technology	[Disabled]	

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
Hyper-threading (Note1)	Disabled Enabled	Enabled for Windows XP and Linux (OS optimized for Hyper-Threading Technology) and Disabled for other OS (OS not optimized for Hyper-Threading Technology). When Disabled only one thread per enabled core is enabled.
Active Processor Cores	All 1	Number of cores to enable in each processor package.
Limit CPUID Maximum	Disabled Enabled	Disabled for Windows XP
Execute Disable Bit	Disabled Enabled	XD can prevent certain classes of malicious buffer overflow attacks when combined with supporting OS (Windows Server 2003 SP1, Windows XP SP2, SuSE Linux 9.2, RedHat Enterprise 3 Update 3.)
Intel Virtualization Technology	Disabled Enabled	When enabled, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology.

Note1: Not present if using CPU not supporting this feature.


Notes:

Intel HT Technology (Hyper Threading Technology) is a performance feature which allows one core on the processor to appear like 2 cores to the operating system. This doubles the execution resources available to the O/S, which potentially increases the performance of your overall system.

Intel VT-x Technology (Virtualization Technology) Previously codenamed "Vanderpool", VT-x represents Intel's technology for virtualization on the x86 platform. In order to support "Virtualization Technology" the CPU must support VT-x and the BIOS setting "Intel Virtualization Technology" must be enabled.

Intel SMX Technology (Safer Mode Extensions Technology) is a part of the Trusted Execution Technology.

10.2.5 Advanced - SATA Configuration



(Scroll indicator bar)

Note: By scrolling down (or up) also settings for Serial ATA Port 3 - 5 can be accessed.

Function	Selection	Description
SATA Controller(s)	Disabled Enabled	Enable or Disable SATA Device.
SATA Mode Selection	IDE ACHI RAID	Determines how SATA controller(s) operate.
SATA Controller Speed	Gen1 Gen2 Gen3	Indicates the maximum speed the SATA controller can support.

Note: in the above BIOS menu the functions below the submenu *Software Feature Mask Configuration* will be described after the submenu description.

Software Feature Mask Configuration

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Advanced

RAID0	[Enabled]	Enables or Disables RAID0 feature.
RAID1	[Enabled]	
RAID10	[Enabled]	
RAID5	[Enabled]	
Intel Rapid Recovery Technology	[Enabled]	
OROM UI and BANNER	[Enabled]	
HDD Unlock	[Enabled]	
LED Locate	[Enabled]	
IRRT Only on eSATA	[Enabled]	
Smart Response Technology	[Enabled]	
OROM UI Delay	[2 Seconds]	
		→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Submenu *Software Feature Mask Configuration* description:

Function	Selection	Description
RAID0	Disabled Enabled	Enable or disable RAID0 feature.
RAID1	Disabled Enabled	Enable or disable RAID1 feature.
RAID10	Disabled Enabled	Enable or disable RAID10 feature.
RAID5	Disabled Enabled	Enable or disable RAID5 feature.
Intel Rapid Recovery Technology	Disabled Enabled	Enable or disable Intel Rapid Recovery Technology.
OROM UI and BANNER	Disabled Enabled	If enabled, then the OROM UI is shown. Otherwise, no OROM banner or information will be displayed if all disks and RAID volumes are Normal.
HDD Unlock	Disabled Enabled	If enabled, indicates that the HDD password unlock in the OS is enabled.
LED Locate	Disabled Enabled	If enabled, indicates that the LED/SGPIO hardware is attached and ping to locate feature is enabled on the OS.
IRRT Only on eSATA	Disabled Enabled	If enabled, then only IRRT volumes can span internal and eSATA drives. If disabled, then any RAID volume can span internal and eSATA drives.
Smart Response Technology	Disabled Enabled	Enable or disable Smart Response Technology
OROM UI Delay	2 Seconds 4 Seconds 6 Seconds 8 Seconds	If enabled, indicates the delay of the OROM UI Splash Screen in normal status.

Remaining *SATA Configuration* menu description:

Function	Selection	Description
Port 0	Disabled Enabled	Enable or Disable SATA Port.
Hot Plug	Disabled Enabled	Designates this port as Hot Pluggable.
External SATA	Disabled Enabled	External SATA Support.
SATA Device Type	Hard Disk Drive Solid State Drive	Identify the SATA port is connected to Solid State Drive or Hard Disk Drive.
Spin Up Device	Disabled Enabled	On an edge detect from 0 to 1, the PCH starts a COMRESET initialization sequence to the device.
Port 1	Disabled Enabled	Enable or Disable SATA Port.
Hot Plug	(see same function above)	(see same function above)
External SATA	(see same function above)	(see same function above)
SATA Device Type	(see same function above)	(see same function above)
Spin Up Device	(see same function above)	(see same function above)
Port 2	Disabled Enabled	Enable or Disable SATA Port.
Hot Plug	(see same function above)	(see same function above)
External SATA	(see same function above)	(see same function above)
Spin Up Device	(see same function above)	(see same function above)
Port 3	Disabled Enabled	Enable or Disable SATA Port.
Hot Plug	(see same function above)	(see same function above)
External SATA	(see same function above)	(see same function above)
Spin Up Device	(see same function above)	(see same function above)
Port4	Disabled Enabled	Enable or Disable SATA Port.
Hot Plug	(see same function above)	(see same function above)
External SATA	(see same function above)	(see same function above)
Spin Up Device	(see same function above)	(see same function above)
Port5	Disabled Enabled	Enable or Disable SATA Port.
Hot Plug	(see same function above)	(see same function above)
External SATA	(see same function above)	(see same function above)
Spin Up Device	(see same function above)	(see same function above)

10.2.6 Advanced - Intel® Rapid Start Technology

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Advanced

Intel® Rapid Start Technology No valid iFFS partition found. Entry on S3 RTC Wake Entry After Active Page Threshold Support iFFS Display Save/Restore	[Enabled] [Enabled] [10 minutes] [Disabled] [Disabled]	Enable or disable Intel® Rapid Start Technology. →← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
--	--	---

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
Intel® Rapid Start Technology	Disabled Enabled	Enable or disable Intel® Rapid Start Technology.
Entry on S3 RTC Wake	Enabled Disabled	iFFS invocation upon S3 RTC wake.
Entry After	Immediately 1 minute 2 minutes 5 minutes 10 minutes 15 minutes 30 minutes 1 hour 2 hours	Enable RTC wake timer at S3 entry.
Active Page Threshold Support	Disabled Enabled	Support RST with small partition.
iFFS Display Save/Restore	Disabled Enabled	iFFS Display Save/Restore.

10.2.7 Advanced - Intel TXT (LT) Configuration

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Advanced

<p>Intel Trusted Execution Technology Configuration</p> <p>Intel TXT support only can be enabled/disabled if SMX is enabled. VT and VT-d support must also be enabled prior to TXT.</p>		<p>Enables or Disables Intel ® TXT (LT) support.</p>
Secure Mode Extensions (SMX)	Enabled	
Intel TXT support	[Disabled]	<p>→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</p>

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

SMX (Intel Secure Mode Extension) instructions are enabled if supported by the CPU, so no BIOS settings are present.

VT (Intel Virtualization Technology) is enabled/disabled in the menu: *Advanced > CPU Configuration*.

VT-d can be enabled/disabled in the menu: *Chipset > System Agent (SA) Configuration*.

Function	Selection	Description
Intel TXT support	Disabled Enabled	Enables or Disables Intel ® TXT (LT) support.

10.2.8 Advanced - Intel® Anti-Theft Technology Configuration

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Advanced

Intel® Anti-Theft Technology Configuration Intel® Anti-Theft Technology [Disabled] Intel® Anti-Theft Technology Rec 3 Enter Intel® AT Suspend Mode [Disabled]		Enables or Disables Intel® AT in BIOS for testing only.
		→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
Intel® Anti-Theft Technology	Disabled Enabled	Enables or Disables Intel® AT in BIOS for testing only.
Intel® Anti-Theft Technology Rec	3 (allowed 1 – 64)	Set the number of times Recovery attempt will be allowed.

10.2.9 Advanced - AMT Configuration

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Advanced		
Intel AMT	[Disabled]	Enable/Disable Intel ® Active Management Technology BIOS Extension. Note: iAMT H/W is always enabled. This option just controls the BIOS Extension execution. If enabled, this requires additional firmware in the SPI device.
BIOS Hotkey Pressed	[Disabled]	
MEBx Selection Screen	[Disabled]	
Hide Un-Configure ME Confirmation	[Disabled]	
MEBx Debug Message Output	[Disabled]	
Un-Configure ME	[Disabled]	
AMT Wait Timer	0	
Disable ME	[Disabled]	
ASF	[Enabled]	
Active Remote Assistance Process	[Disabled]	
USB Configure	[Enabled]	
PET Progress	[Enabled]	
AMT CIRA Timeout	0	
Watchdog	[Disabled]	
OS Timer	0	
BIOS Timer	0	
→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit		

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
Intel AMT	Disabled Enabled	Enable/Disable Intel ® Active Management Technology BIOS Extension. Note: iAMT H/W is always enabled. This option just controls the BIOS Extension execution. If enabled, this requires additional firmware in the SPI device.
BIOS Hotkey Pressed (Note1)	Disabled Enabled	OEMFlag Bit 1: Enable/Disabled BIOS hotkey press.
MEBx Selection Screen (Note1)	Disabled Enabled	OEMFlag Bit 2: Enable/Disabled BIOS MEBx Selection Screen.
Hide Un-Configure ME Confirmation (Note1)	Disabled Enabled	OEMFlag Bit 6: Hide Un-Configure ME without password Confirmation Prompt
MEBx Debug Message Output (Note1)	Disabled Enabled	OEMFlag Bit 14: Enable MEBx Debug Message Output.
Un-Configure ME (Note1)	Disabled Enabled	OEMFlag Bit 15: Un-Configure ME without password.

Function	Selection	Description
AMT Wait Timer (Note1)	0 - 65535 (Note4)	Set timer to wait before sending ASF_GET_BOOT_OPTIONS.
Disable ME (Note1)	Disabled Enabled	Set ME to Soft Temporary Disabled.
ASF (Note1)	Disabled Enabled	Enable/Disabled Alert Specification Format.
Active Remote Assistance Process (Note1)	Disabled Enabled	Trigger CIRA boot.
USB Configure (Note1)	Disabled Enabled	Enable/Disable USB Configure function.
PET Progress (Note1)	Disabled Enabled	Users can Enable/Disable PET Events progress to receive PET events or not.
AMT CIRA Timeout (Note1) (Note5)	0 – 255 (Note4)	OEM defined timeout for MPS connection to be established. 0 – use the default timeout value of 60 seconds. 255 – MEBX waits until the connection succeeds.
Watchdog (Note2)	Disabled Enabled	Enable/Disable Watchdog Timer.
OS Timer (Note3)	0 - 65535 (Note4)	Set OS watchdog timer.
BIOS Timer (Note3)	0 - 65535 (Note4)	Set BIOS Watchdog Timer.

Note1: Only if Intel AMT = Enabled.

Note2: This Watchdog function is unsupported.

Recommendation, use Watchdog function present in *Hardware Health Configuration* menu.

Note3: Only if Watchdog = Enabled.

Note4: To enter number use digit keys and/or +/- keys.

Note5: Only if Active Remote Assistance Process = Enabled.

10.2.10 Advanced - Acoustic Management Configuration

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Advanced

Acoustic Management Configuration		Option to Enable or Disable Automatic Acoustic Management
Automatic Acoustic Management	[Disabled]	
Sata Port 0 ST3120827AS Acoustic Mode	[Not Available]	
		→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
Automatic Acoustic Management	Enabled Disabled	Option to Enable or Disable Automatic Acoustic Management.

Note:

Automatic acoustic management (AAM) is a method for reducing acoustic emanations in AT Attachment (ATA) mass storage devices, such as ATA hard disk drives and ATAPI optical disc drives. AAM is an optional feature set for ATA/ATAPI devices; when a device supports AAM, the acoustic management parameters are adjustable through a software or firmware user interface.

The ATA/ATAPI sub-command for setting the level of AAM operation is an 8-bit value from 0 to 255. Most modern drives ship with the vendor-defined value of 0x00 in the acoustic management setting. This often translates to the max-performance value of 254 stated in the standard. Values between 128 and 254 (0x80 - 0xFE) enable the feature and select most-quiet to most-performance settings along that range. Though hard drive manufacturers may support the whole range of values, the settings are allowed to be banded so many values could provide the same acoustic performance.

10.2.11 Advanced - USB Configuration

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.


Advanced

USB Configuration		Enables Legacy USB support. AUTO option disables legacy support if no USB devices are connected. DISABLE option will keep USB devices available only for EFI applications.
USB Devices: 2 Hubs		
Legacy USB Support	[Enabled]	→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
USB Mass Storage Driver Support	[Enabled]	
USB transfer time-out	[20 sec]	
Device reset time-out	[20 sec]	
Device power-up delay	[Auto]	

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
Legacy USB Support	Enabled Disabled Auto	Enables Legacy USB support. AUTO option disables legacy support if no USB devices are connected. DISABLE option will keep USB devices available only for EFI applications.
USB Mass Storage Driver Support	Enabled Disabled	Enable/disable USB Mass Storage Driver Support.
USB transfer time-out	1 sec 5 sec 10 sec 20 sec	The time-out value for Control, Bulk, and Interrupt transfers.
Device reset time-out	10 sec 20 sec 30 sec 40 sec	USB mass storage device Start Unit command time-out.
Device power-up delay	Auto Manual	Maximum time the device will take before it properly reports itself to the Host Controller. 'Auto' uses default value: for a Root port it is 100 ms, for a Hub port the delay is taken from Hub descriptor.

10.2.12 Advanced - SMART Settings




Function	Selection	Description
SMART Self Test	Disabled Enabled	Run SMART Self-Test on all HDDs during POST.

Note:

S.M.A.R.T. (Self-Monitoring, Analysis and Reporting Technology; often written as SMART) is a monitoring system for computer hard disk drives to detect and report on various indicators of reliability, in the hope of anticipating failures.

10.2.13 Advanced - Super IO Configuration



The 5 submenus are shown and described on the following pages.

Serial Port 1 Configuration

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Advanced

Serial Port 1 Configuration		Enable or Disable Serial Port (COM)
Serial Port	[Enabled]	
Device Settings	IO=3F8h; IRQ=4;	
Change Settings	[Auto]	
		→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
Serial Port	Disabled Enabled	Enable or Disable Serial Port (COM)
Change Settings (Note1)	Auto IO=3F8h; IRQ=4; IO=3F8h; IRQ=3,4,5,6,7,10,11,12; IO=2F8h; IRQ=3,4,5,6,7,10,11,12; IO=3E8h; IRQ=3,4,5,6,7,10,11,12; IO=2E8h; IRQ=3,4,5,6,7,10,11,12;	Select an optimal setting for Super IO device.

Note1: only if Serial Port = Enabled

Serial Port 2 Configuration

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Advanced

Serial Port 2 Configuration		Enable or Disable Serial Port (COM)
Serial Port	[Enabled]	
Device Settings	IO=2F8h; IRQ=3;	
Change Settings	[Auto]	
		→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
Serial Port	Disabled Enabled	Enable or Disable Serial Port (COM)
Change Settings (Note1)	Auto IO=2F8h; IRQ=3; IO=3F8h; IRQ=3,4,5,6,7,10,11,12; IO=2F8h; IRQ=3,4,5,6,7,10,11,12; IO=3E8h; IRQ=3,4,5,6,7,10,11,12; IO=2E8h; IRQ=3,4,5,6,7,10,11,12;	Select an optimal setting for Super IO device.

Note1: only if Serial Port = Enabled

Serial Port 3 Configuration

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Advanced

<p>Serial Port 3 Configuration</p> <p>Serial Port Device Settings</p> <p>Change Settings Device Mode</p>	<p>[Enabled] IO=3E8h; IRQ=7;</p> <p>[Auto] [Standard Serial Po...]</p>	<p>Enable or Disable Serial Port (COM)</p>
		<p>→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</p>

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
Serial Port	Disabled Enabled	Enable or Disable Serial Port (COM)
Change Settings (Note1)	Auto IO=3E8h; IRQ=7; IO=3F8h; IRQ=3,4,5,6,7,10,11,12; IO=2F8h; IRQ=3,4,5,6,7,10,11,12; IO=3E8h; IRQ=3,4,5,6,7,10,11,12; IO=2E8h; IRQ=3,4,5,6,7,10,11,12;	Select an optimal setting for Super IO device.
Device Mode (Note1)	Standard Serial Port Mode IrDA 1.0 (HP SIR) Mode ASKIR Mode	Change the Serial Port mode. Select <High Speed> or <Normal mode> mode.

Note1: only if Serial Port = Enabled

Serial Port 4 Configuration

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Advanced

<p>Serial Port 4 Configuration</p> <p>Serial Port Device Settings</p> <p>Change Settings Device Mode</p>	<p>[Enabled] IO=2E8h; IRQ=10;</p> <p>[Auto] [Standard Serial Po...]</p>	<p>Enable or Disable Serial Port (COM)</p>
		<p>→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</p>

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
Serial Port	Disabled Enabled	Enable or Disable Serial Port (COM)
Change Settings (Note1)	Auto IO=2E8h; IRQ=10; IO=3F8h; IRQ=3,4,5,6,7,10,11,12; IO=2F8h; IRQ=3,4,5,6,7,10,11,12; IO=3E8h; IRQ=3,4,5,6,7,10,11,12; IO=2E8h; IRQ=3,4,5,6,7,10,11,12;	Select an optimal setting for Super IO device.
Device Mode (Note1)	Standard Serial Port Mode IrDA 1.0 (HP SIR) Mode ASKIR Mode	Change the Serial Port mode. Select <High Speed> or <Normal mode> mode.

Note1: only if Serial Port = Enabled

10.2.14 Advanced - Voltage Monitor

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Advanced

Voltage Monitor	
VCore	: 0.968 V
1.05	: 1.048 V
1.5	: 1.512 V
3.3	: 3.392 V
3.3SB	: 3.392 V
5	: 5.188 V
12	: 12.144 V
VBAT	: 3.150 V

→← : Select Screen
↑↓ : Select Item
Enter: Select
+/- : Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

10.2.15 Advanced - Hardware Health Configuration

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.		
Advanced		
Hardware Health Configuration		Disabled = Full speed.
System Temperature	: 30°C/86°F	Thermal: does regulate fan speed according to specified temperature.
System Temperature Ext	: 24°C/75°F	
CPU Temperature	: 49.10°C/120°F	
System Fan Speed	: 1543 RPM	Speed: does regulate according to specified RPM.
System Temperature Ext Type	[OneWire @ GPIO16]	
Fan Cruise Control	[Thermal]	
Fan Settings	35	
Fan Min limit	0	
Fan Max limit	100	
CPU Fan Speed	: 1374 RPM	→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Fan Cruise Control	[Thermal]	
Fan Settings	50	
Fan Min limit	0	
Fan Max limit	100	
Watchdog Function	0	
PC Speaker/Beep	[Enabled]	

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
System Temperature Ext Type (note1)	Disabled LM75 @ 0x90 OneWire @ GPIO16	Use external connected sensor instead of onboard.
Fan Cruise Control (System Fan)	Disabled Thermal (note2) Speed	Disabled = Full speed. Thermal: Regulate according to specified °C. Speed: Regulate according to specified RPM.
Fan Settings (System Fan)	30 – 90 (note2,note3) 1000 – 9999 (note4)	Specify limit temperature in °C or limit RPM (depending on Thermal or Speed selection)
Fan Min limit (System Fan) (note5)	0 (note6)	Minimum PWM %, can be used to make sure fan is always active. Make sure Min limit < Max limit.
Fan Max limit (System Fan) (note5)	100 (note6)	Maximum PWM %, can be used to limit the fan noise. Make sure Min limit < Max limit.
Fan Cruise Control (CPU Fan)	Disabled Thermal Speed	Disabled = Full speed. Thermal: Regulate according to specified °C. Speed: Regulate according to specified RPM.
Fan Settings (CPU Fan)	30 – 90 (note3) 1000 – 9999 (note4)	Specify limit temperature in °C or limit RPM (depending on Thermal or Speed selection)
Fan Min limit (CPU Fan) (note7)	0 (note6)	Minimum PWM %, can be used to make sure fan is always active. Make sure Min limit < Max limit.
Fan Max limit (CPU Fan) (note7)	100 (note6)	Maximum PWM %, can be used to limit the fan noise. Make sure Min limit < Max limit.
Watchdog Function	0 - 255 (note8)	0 = Disabled. Enter the service interval in seconds before system will reset. Refer to manual how to reload the timer.
PC Speaker/Beep	Disabled Enabled	Control the default beeps during boot of the system. This setting will also control the beep during enumeration and (un)plug of USB.

Note1: Only visible if external temperature sensor like PN1053-4925 "Cable Temperature Sensor - 44P, 400 mm" is connected.

Note2: Only visible if external temperature sensor is connected and if System Temperature Ext Type is not Disabled.

Note3: °C (if Fan Cruise Control = Thermal) use either digit keys to enter value or +/- keys to increase/decrease value. Don't use mix of digit keys and +/- keys.

Note4: RPM (if Fan Cruise Control = Speed) use either digit keys to enter value or +/- keys to increase/decrease value by 100. Don't use mix of digit keys and +/- keys.

Note5: Only visible if external temperature sensor is connected and if System Fan Cruise Control is Thermal.

Note6: Use number keys to enter value.

Note7: Only visible if CPU Fan Cruise Control is Thermal.

Note8: Seconds, use digit keys to enter value. Value 0 means Watchdog is disabled. Refer to "KT-API-V2 User Manual" to control the Watchdog via API or refer to "KT-API-V2 User Manual DLL" how to control Watchdog via Windows DLL.

10.2.16 Advanced - LAN Configuration

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Advanced

<p>LAN Configuration System UUID {f4af2da3-b59d-58a9-466cb11a02b0486f}</p> <p>ETH1 Configuration (Left) [Enabled] Wake on LAN [Enabled] MAC Address & Link status: 00E0F4288EA3+</p> <p>ETH2 Configuration (Upper) [Enabled] MAC Address & Link status: 00E0F4288EA4-</p> <p>ETH3 Configuration (Lower) [Enabled] MAC Address & Link status: N/A</p> <p>▶ Network Stack</p>	<p>Control of Ethernet Devices and PXE boot. To disable ETH1, ME Subsystem must be as well.</p>
	<p>→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</p>

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
ETH1 Configuration (Left)	Disabled Enabled With PXE boot	Control of Ethernet Devices and PXE boot. To disable ETH1, ME Subsystem must be as well.
Wake on LAN	Enabled Disabled	Enable or disable integrated LAN to wake the system. (The Wake On LAN cannot be disabled if ME is on at Sx state.)
ETH2 Configuration (Upper) (right)	Disabled Enabled With PXE boot	Control of Ethernet Devices and PXE boot. To disable ETH2, ME Subsystem must be as well.
ETH3 Configuration (Lower)	Disabled Enabled With PXE boot	ETH3 is not available on the KTQM67/Flex-Medical. This setting has no effect.

Network Stack

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Advanced

Network stack	[Enable]	Enable/Disable UEFI network stack.
Ipv4 PXE Support	[Enable]	
Ipv6 PXE Support	[Enable]	
Ipv6 Delay Time	0	

→← : Select Screen
 ↑↓ : Select Item
 Enter: Select
 +/- : Change Opt.
 F1: General Help
 F2: Previous Values
 F3: Optimized Defaults
 F4: Save & Exit
 ESC: Exit


Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
Network stack	Disable Link Enabled	Enable/Disable UEFI network stack.
Ipv4 PXE Support (Note1)	Enabled Disabled	Enable Ipv4 PXE Boot Support. If disabled IPV4 PXE boot option will not be created.
Ipv6 PXE Support (Note1)	Enabled Disabled	Enable Ipv6 PXE Boot Support. If disabled IPV6 PXE boot option will not be created.
IPv6 Delay Time (Note1)	0 – 15 (Note2)	Set Seconds of Delay Before IPv6 PXE Boot. Default 0 Seconds.

Note1: Only if Network stack = Enabled.

Note2: To enter number use digit keys and/or +/- keys.

10.2.17 Advanced - Delay Startup



Function	Selection	Description
Delay Startup	0 – 9999 Note1)	Delay startup value is in ms.

Note1: To enter number use digit keys and/or +/- keys.

The delay initiates if the value is different from 0, starts at the earliest possible point of the BIOS boot. For some add-on devices the BIOS boot is too fast for proper detection. In other words, the setting is meant as a possible fix to Add-on device detection problems.

10.2.18 Advanced - Serial Port Console Redirection

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.		
Advanced		
COM0 Console Redirection ▶ Console Redirection Settings	[Disabled]	Console Redirection Enable or Disable.
COM1 Console Redirection ▶ Console Redirection Settings	[Disabled]	
COM2 Console Redirection ▶ Console Redirection Settings	[Disabled]	
COM3 Console Redirection ▶ Console Redirection Settings	[Disabled]	
COM4(Pci Bus0,Dev0,Func0) (Disabled) Console Redirection Serial Port for Out-of-Band Management/ Windows Emergency Management Services (EMS) Console Redirection ▶ Console Redirection Settings	Port Is Disabled [Disabled]	→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.15.1236. Copyright © 2012 American Megatrends, Inc		

Console Redirection Settings

The "Console Redirection Settings" Menus are only available if related "Console Redirection" is Enabled. A different menu is available for Serial Port for Out-of-Band Management, see next page.

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.		
Advanced		
COM0 Console Redirection Settings		Emulation: ANSI: Extended ASCII char set. VT100: ASCII char set. VT100+: Extends VT100 to support color, function keys, etc. VT-UTF8: Uses UTF8 encoding to map Unicode chars onto 1 or more bytes.
Terminal Type	[ANSI]	
Bits per second	[115200]	
Data Bits	[8]	
Parity	[None]	
Stop Bits	[1]	
Flow Control	[None]	
VT-UTF8 Combo Key Support	[Enabled]	
Recorder Mode	[Disabled]	
Resolution 100x31	[Disabled]	
Legacy OS Redirection Resolution	[80x24]	
Putty Keypad	[VT100]	→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Redirection After BIOS POST	[Always Enable]	
Version 2.15.1236. Copyright © 2012 American Megatrends, Inc		

Function	Selection	Description
Terminal Type	VT100 VT100+ VT-UTF8 ANSI	Emulation: ANSI: Extended ASCII char set. VT100: ASCII char set. VT100+: Extends VT100 to support color, function keys, etc. VT-UTF8: Uses UTF8 encoding to map Unicode chars onto 1 or more bytes.
Bits per second	9600 19200 38400 57600 115200	Select serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds.
Data Bits	7, 8	Data Bits
Parity	None Even Odd Mark Space	A parity bit can be sent with the data bits to detect some transmission errors. Even: parity bit is 0 if the num of 1's in the data bits is even. Odd: parity bit is 0 if the num of 1's in the data bits is odd. Mark: parity bit is always 1. Space: parity bit is always 0. Mark/Space do not allow error detection.
Stop Bits	1 2	Stop bits indicate the end of a serial data packet. (A start bit indicates the beginning). The standard setting is 1 stop bit. Communication with slow devices may require more than 1 stop bit.
Flow Control	None Hardware RTS/CTS	Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a 'stop' signal can be sent to stop the data flow. Once the buffers are empty, a 'start' signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals.
VT-UTF8 Combo Key Support	Disabled Enabled	Enable VT-UTF8 Combination Key Support for ANSI/VT100 terminals.
Recorder Mode	Disabled Enabled	On this mode enabled only text will be send. This is to capture Terminal data.
Resolution 100x31	Disabled Enabled	Enables or disables extended terminal resolution.
Legacy OS Redirection Resolution	80x24 80x25	On Legacy OS, the Number of Rows and Columns supported redirection.
Putty Keypad	VT100 LINUX XTERMR6 SCO ESCN VT400	Select FunctionKey and KeyPad on Putty.
Redirection After BIOS POST	Always Enable BootLoader	The settings specify if BootLoader is selected than Legacy console redirection is disabled before booting to Legacy OS. Default value is Always Enable which means Legacy console Redirection is enabled for Legacy OS.

When "Serial Port for Out-of-Band Management/Windows Emergency Management Services (EMS)" > "Console Redirection" is enabled:

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.


Advanced

Out-of-Band Mgmt Port Terminal Type Bits per second Flow Control Data Bits Parity Stop Bits	[COM0] [VT-UTF8] [115200] [None] 8 None 1	Microsoft Windows Emergency Management Services (EMS) allows for remote management of a Windows Server OS through a serial port.
		→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit


Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
Out-of-Band Mgmt Port	COM0 COM1 COM2 COM3 COM4	Microsoft Windows Emergency Management Services (EMS) allows for remote management of a Windows Server OS through a serial port.
Terminal Type	VT100 VT100+ VT-UTF8 ANSI	VT-UTF8 is the preferred terminal type for out-of-band management. The next best choice is VT100+ and then VT100. See above, in Console Redirection Settings page, for more Help with Terminal Type/Emulation.
Bits per second	9600 19200 57600 115200	Select serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds.
Flow Control	None Hardware RTS/CTS Software Xon/Xoff	Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a 'stop' signal can be sent to stop the data flow. Once the buffers are empty, a 'start' signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals.

10.3 Chipset



10.3.1 PCH-IO Configuration



Please find description of the “PCI Express Configuration”, “USB Configuration” and “PCH Azalia Configuration” on the following pages.

Function	Selection	Description
Restore AC Power Loss	Power Off Power On Last State	Select AC Power state when power is re-applied after a power failure.

PCI Express Configuration

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Chipset

PCI Express Configuration Subtractive Decode [Enabled] Subtractive Decode Port# 0 ▶ PCI Express Root Port 1 ▶ PCI Express Root Port 2 ▶ PCI Express Root Port 4 ▶ PCI Express Root Port 5		Enable or disable PCI Express Subtractive Decode. →← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
--	--	--

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
Subtractive Decode	Disabled Enabled	Enable or disable PCI Express Subtractive Decode.
Subtractive Decode Port# (Note1)	0 (Note2)	Select PCI Express Subtractive Decode Root Port. User to ensure port availability.

Note1: Only visible if "Subtractive Decode" is Enabled.

Note2: To enter number use digit keys and/or +/- keys.

PCI Express Root Port (1-2, 4-5)

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Chipset

PCI Express Root Port (1-2, 4-5)	[Enabled]	Control the PCI Express Root Port.
ASPM Support	[Disabled]	
PME SCI	[Enabled]	
PCIe Speed	[Auto]	

→← : Select Screen
↑↓ : Select Item
Enter: Select
+/- : Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
PCI Express Root Port (1-2, 4-5)	Disabled Enabled	Control the PCI Express Root Port.
ASPM Support	Disabled L0s L1 L0sL1 Auto	Set the ASPM Level. Disabled: Disabled ASPM L0s: Force all links to L0s State Auto: BIOS auto configure
PME SCI	Disabled Enabled	Enable or disable PCI Express PME SCI.
PCIe Speed	Auto Gen1 Gen2	Select PCI Express port speed.

USB Configuration

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Chipset

USB Configuration		Enable or disable XHCI Pre-Boot Driver support.
ECHI1	[Enabled]	
ECHI2	[Enabled]	
USB Ports Per-Port Disable Control	[Disabled]	
		→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
ECHI1	Disabled Enabled	Control the USB EHCI (USB 2.0) functions. One EHCI controller must always be enabled.
ECHI2	Disabled Enabled	Control the USB EHCI (USB 2.0) functions. One EHCI controller must always be enabled.
USB Ports Per-Port Disable Control	Disabled Enabled	Control each of the USB ports (0 – 13) disabling.
USB Port #(0-13) Disabled (Note1)	Disabled Enabled	Disabled USB port.

Note1: Only visible if “USB Ports Per-Port Disable Control” is Enabled.

PCH Azalia Configuration

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Chipset

PCH Azalia Configuration		Control Detection of the Azalia device. Disabled = Azalia will be unconditionally disabled. Enabled = Azalia will be unconditionally enabled. Auto = Azalia will be enabled if present, disabled otherwise.
Azalia	[Auto]	
Audio Jack Sensing	[Auto]	
Azalia Internal HDMI codec	[Enabled]	
Azalia HDMI codec Port B	[Enabled]	
Azalia HDMI codec Port C	[Enabled]	
Azalia HDMI codec Port D	[Enabled]	

→← : Select Screen
↑↓ : Select Item
Enter: Select
+/- : Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
Azalia	Disabled Enabled Auto	Control Detection of the Azalia device. Disabled = Azalia unconditionally disabled. Enabled = Azalia unconditionally enabled. Auto = Azalia enabled if present, disabled otherwise.
Audio Jack Sensing (Note1)	Disabled Auto	Audio Jacks are not available on the KTQM67/Flex-Medical. To enable the audio on the Audio Pin header connector select Disable.
Azalia Internal HDMI codec (Note1)	Disabled Enabled	Enable or disable internal HDMI codec for Azalia.
Azalia HDMI codec PortB Azalia HDMI codec PortC Azalia HDMI codec PortD (Note2)	Disabled Enabled	Enable or disable internal HDMI codec for Azalia.

Note1: Only visible if "Azalia is not Disabled.

Note2: Only visible if "Azalia is not Disabled and "Azalia Internal HDMI codec" is Enabled.

10.3.2 System Agent (SA) Configuration

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Chipset

System Agent Bridge Name	SandyBridge	Check to enable VT-d function on MCH.
System Agent Bridge Name	1.8.0.0	
VT-d Capability	Unsupported	
VT-d	[Enabled]	→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
CHAP Device (B0:D7:F0)	[Disabled]	
Thermal Device (B0:D4:F0)	[Disabled]	
Enable NB CRID	[Disabled]	
BDAT ACPI Table Support	[Disabled]	
C-State Pre-Wake	[Enabled]	
▶ Graphics Configuration ▶ DMI Configuration ▶ NB PCIe Configuration ▶ Memory Configuration ▶ Memory Thermal Configuration ▶ GT – Power Management Control		

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
VT-d (Note1)	Disabled Enabled	Check to enable VT-d function on MCH.
CHAP Device (B0:D7:F0)	Enabled Disabled	Enable or disable SA CHAP Device.
Thermal Device (B0:D4:F0)	Enabled Disabled	Enable or disable SA Thermal Device.
Enable NB CRID	Enabled Disabled	Enable or disable NB CRID Workaround.
BDAT ACPI Table Support	Enabled Disabled	Enables support for the BDAT ACPI Table.
C-State Pre-Wake (Note2)	Enabled Disabled	Controls C-State Pre-Wake feature for ARAT, in SSKPD[57]

Note 1: Only present if supported by CPU.

Note 2: Only present if Ivy Bridge CPU is used.

Graphics Configuration

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Chipset

Graphics Configuration		Graphics turbo IMON current values supported (14 – 31).
IGFX VBIOS Version	2153	
IGFX Frequency	850 MHz	
Graphics Turbo IMON Current	31	
Primary Display	[Auto]	
Internal Graphics	[Auto]	
GTT Size	[2MB]	
Aperture Size	[256MB]	
DVMT Pre-Allocated	[64M]	
DVMT Total Gfx Mem	[256M]	
Gfx Low Power Mode	[Enabled]	
Graphics Performance Analyzers	[Disabled]	
▶ LCD Control		→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
Graphics Turbo IMON Current	31	Graphics turbo IMON current values supported (14 – 31).
Primary Display	Auto IGFX PEG PCI	Select which of IGFX/PEG/PCI Graphics device should be Primary Display Or select SG for Switchable Gfx.
Internal Graphics	Auto Disabled Enabled	Keep IGD enabled based on the setup options.
GTT Size	1MB 2MB	Select the GTT Size.
Aperture Size	128MB 256MB 512MB	Select the Aperture Size.
DVMT Pre-Allocated	32M, 64M , 96M, 128M, 160M, 192M, 224M, 256M, 288M, 320M, 352M, 384M, 416M, 448M, 480M, 512M, 1024M	Select DVMT 5.0 Pre-Allocated (Fixed) Graphics Memory size used by the Internal Graphics Device.
DVMT Total Gfx Mem	128M 256M MAX	Select DVMT 5.0 Total Graphics Memory size used by the Internal Graphics Device.
Gfx Low Power Mode	Enabled Disabled	This option is applicable for SSF only.
Graphics Performance Analyzers	Enabled Disabled	Enable or disable Intel Graphics Performance Analyzers Counters.

LCD Control

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.		
Chipset		
LCD Control		Select the Video Device which will be activated during POST. This has no effect if external graphics present. Secondary boot display selection will appear based on your selection. VGA modes will be supported only on primary display.
Primary IGFX Boot Display	[VBIOS Default]	
LCD Panel Type	[VBIOS Default]	
SDVO-LFP Panel Type	[VBIOS Default]	
Panel Scaling	[Auto]	
Backlight Control	[PWM Inverted]	
BIA	[Auto]	
Spread Spectrum clock Chip	[Off]	
TV1 Standard	[VBIOS Default]	
TV2 Standard	[VBIOS Default]	
ALS Support	[Disabled]	
Active LFP	[No LVDS]	
Panel Color Depth	[18 Bit]	
		→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.15.1236. Copyright © 2012 American Megatrends, Inc		

Function	Selection	Description
Primary IGFX Boot Display	VBIOS Default CRT (DVI-A, default 1) EFP (DVI-D, default 1) LFP (LVDS display) EFP3 (DP2 display) EFP2 (DP1, default 2) LFP2	Select the Video Device which will be activated during POST. This has no effect if external graphics present. Secondary boot display selection will appear based on your selection. VGA modes will be supported only on primary display.
LCD Panel Type	VBIOS Default 640x480 LVDS 800x600 LVDS 1024x768 LVDS1 1280x1024 LVDS 1400x1050(RB) LVDS1 1400x1050 LVDS2 1600x1200 LVDS 1366x768 LVDS 1680x1050 LVDS 1920x1200 LVDS 1440x900 LVDS 1600x900 LVDS 1024x768 LVDS2 1280x800 LVDS 1920x1080 LVDS 2048x1536 LVDS	Select LCD panel used by Internal Graphics Device by selecting the appropriate setup item.
SDVO-LFP Panel Type	VBIOS Default 1024x768 SDVO-LFP 1280x1024 SDVO-LFP 1400x1050 SDVO-LFP 1600x1200 SDVO-LFP	Select SDVO panel used by Internal Graphics Device by selecting the appropriate setup item.
Panel Scaling	Auto Off Force Scaling	Select the LCD panel scaling option used by Internal Graphics Device.
Backlight Control	PWM Inverted PWM Normal GMBus Inverted GMBus Normal	Backlight Control Setting
BIA	Auto Disabled Level 1 Level 2 Level 3 Level 4 Level 5	Auto: GMCH use VBT defaults. Level n: Enabled with selected Aggressiveness Level.
Spread Spectrum clock Chip	Off Hardware Software	Hardware: Spread is controlled by chip. Software: Spread is controlled by BIOS.

Function	Selection	Description
TV1 Standard	VBIOS Default NTSC_M NTSC_M_J NTSC_433 PAL_B PAL_G PAL_D PAL_H PAL_I PAL_M PAL_N SECAM_L SECAM_B SECAM_D SECAM_G SECAM_H SECAM_K HDTV_STD_SMPTE_240M_1080i59 HDTV_STD_SMPTE_240M_1080i60 HDTV_STD_SMPTE_295M_1080i50 HDTV_STD_SMPTE_295M_1080p50 HDTV_STD_SMPTE_296M_720p50 HDTV_STD_SMPTE_296M_720p60 HDTV_STD_CEAIEA_7702A_480p60 HDTV_STD_CEAIEA_7702A_480i60	Select the ability to configure a TV Format.
TV2 Standard	VBIOS Default NTSC_M NTSC_M_J NTSC_433 PAL_B PAL_G PAL_D PAL_H PAL_I PAL_M PAL_N SECAM_L SECAM_B SECAM_D SECAM_G SECAM_H SECAM_K HDTV_STD_SMPTE_240M_1080i59 HDTV_STD_SMPTE_240M_1080i60 HDTV_STD_SMPTE_295M_1080i50 HDTV_STD_SMPTE_295M_1080p50 HDTV_STD_SMPTE_296M_720p50 HDTV_STD_SMPTE_296M_720p60 HDTV_STD_CEAIEA_7702A_480p60 HDTV_STD_CEAIEA_7702A_480i60	Select the ability to configure a TV Minor Format.

Function	Selection	Description
ALS Support	Enabled Disabled	Valid only for ACPI. Legacy = ALS Support through the IGD INT10 function. SCPI = ALS support through an ACPI ALS driver.
Active LFP	No LVDS Int-LVDS SDVO LVDS eDP Port-A eDP Port-D	Select the Active LFP Configuration. No LVDS: VBIOS does not enable LVDS. Int-LVDS: VBIOS enables LVDS driver by SDVO encoder. SDVO LVDS: VBIOS enables LVDS driver by SDVO encoder. eDP Port-A: LFP driven by Internal DisplayPort encoder from Port-A.
Panel Color Depth	18 Bit 24 Bit	Select the LFP Panel Color Depth.

DMI Configuration

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Chipset

DMI Configuration		Enable or disable DMI Vc1.
DMI	X4 Gen2	
DMI Vc1 Control	[Enabled]	
DMI Vcp Control	[Enabled]	
DMI Vcm Control	[Enabled]	
DMI Link ASPM Control	[L0sL1]	
DMI Extended Synch Control	[Disabled]	
DMI Gen 2	[Auto]	

→← : Select Screen
↑↓ : Select Item
Enter: Select
+/- : Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
DMI Vc1 Control	Enabled Disabled	Enable or disable DMI Vc1
DMI Vcp Control	Enabled Disabled	Enable or disable DMI Vcp
DMI Vcm Control	Enabled Disabled	Enable or disable DMI Vcm
DMI Link ASPM Control	Disabled L0s L1 L0sL1	Enable or disable the control of Active State Power Management on SA side of the DMI Link.
DMI Extended Synch Control	Enabled Disabled	Enable DMI Extended Synchronization.
DMI Gen 2	Auto Enabled Disabled	Enable or disable DMI Gen 2. Auto means Disabled for IVB A0 MB/DT and IVB B0 MB, Enabled for other CPUs.

NB PCIe Configuration

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Chipset

NB PCIe Configuration		Configure PEG0 B0:D1:F0 Gen1-Gen3
PEG0	Not Present	
PEG0 – Gen X	[Auto]	
PEG0 ASPM	[Disabled]	
Enable PEG	[Auto]	
Detect Non-Compliance Device	[Disabled]	
De-emphasis Control	[-3.5 dB]	
PEG Sampler Calibrate	[Auto]	
Swing Control	[Full]	
PEG Link Disabled	[Disabled]	
Fast PEG Init	[Enabled]	
RxCEM Loop back	[Disabled]	
		→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
PEG0 – Gen X	Auto GEN1 Gen2	Configure PEG0 B0:D1:F0 Gen1-Gen3
PEG0 ASPM	Disabled Auto ASPM L0s ASPM L1 ASPM L0sL1	Control ASPM support for the PEG: Device 1 Function 0. This has no effect if PEG is not the currently active device.
Enable PEG	Disabled Enabled Auto	To enable or disable the PEG.
Detect Non-Compliance Device	Disabled Enabled	Detect Non-Compliance PCI Express Device in PEG.
De-emphasis Control	-6 dB -3.5 dB	Configuring the De-emphasis Control on PEG.
PEG Sampler Calibrate	Auto Enabled Disabled	Enable or disable PEG Sampler Calibrate. Auto means Disabled for SNB MB/DT, Enabled for IVB A0 B0.
Swing Control	Reduced Half Full	Perform PEG Swing Control, on IVB C0 and Later.
PEG Link Disabled	Enabled Disabled	Enable or disable PCIe link disable mechanism for additional power saving.
Fast PEG Init	Enabled Disabled	Enable or disable Fast PEG Init, Some optimization if not PEG devices present in cold boot.
RxCEM Loop back	Enabled Disabled	Enable or disable RxCEM Loop back.

Memory Configuration

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Chipset

Memory Information		Select DIMM timing profile that should be used.
Memory RC Version	1.8.0.0	
Memory Frequency	1333 Mhz	
Total Memory	8192 MB (DDR3)	
DIMM#0	4096 MB (DDR3)	
DIMM#1	4096 MB (DDR3)	
DIMM#2	Not Present	
DIMM#3	Not Present	
CAS Latency (tCL)	9	
Minimum delay time		
CAS to RAS (tRCDmin)	9	
Row Precharge (tRPmin)	9	
Active to Precharge (tRASmin)	24	
XMP Profile 1	Not Supported	
XMP Profile 2	Not Supported	
DIMM profile	[Default DIMM Profile]	→← : Select Screen
Memory Frequency Limiter	[Auto]	↑↓ : Select Item
ECC Support	[Enabled]	Enter: Select
Max TOLUD	[Dynamic]	+/- : Change Opt.
NMode Support	[Auto]	F1: General Help
Memory Scrambler	[Enabled]	F2: Previous Values
MRC Fast Boot	[Enabled]	F3: Optimized Defaults
Force Cold Reset	[Enabled]	F4: Save & Exit
DIMM Exit Mode	[Fast Exit]	ESC: Exit
Power Down Mode	[PPD]	

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
DIMM profile	Default DIMM profile Custom Profile XMP Profile 1 XMP Profile 2	Select DIMM timing profile that should be used.
Memory Frequency Limiter	Auto 1067 1333 1600 1867 2133 2400 2667	Maximum Memory Frequency Selections in Mhz.
ECC Support	Disabled Enabled	Enable or disable DDR Ecc Support.

Table continued:

Function	Selection	Description
Max TOLUD	Dynamic 1 GB 1.25 GB 1.5 GB 1.75 GB 2 GB 3. GB 2.5 GB 2.75 GB 3 GB 3.25 GB	Maximum Value of TOLUD. Dynamic assignment would adjust TOLUD automatically based on largest MMIO length of installed graphic controller.
NMode Support	Auto 1N Mode 2N Mode	Nmode Support Option
Memory Scrambler	Enabled Disabled	Enable or disable memory scrambler.
MRC Fast Boot	Enabled Disabled	Enable or disable MRC Fast Boot
Force Cold Reset	Enabled Disabled	Force cold reset or choose MRC cold reset mode, when cold boot is required during MRC execution. Note: If ME 5.0MB is present, Force cold reset is required!
DIMM Exit Mode	Auto Slow Exit Fast Exit	DIMM Exit Mode control.
Power Down Mode	No Power Down APD PPD APD-PPD	Power Down Mode control.
Scrambler Seed Generation Off	Enabled Disabled	Control Memory Scrambler Seed Generation. Enable – do not generate scrambler seed. Disable – Generate scrambler seed always.
Memory Remap	Enabled Disabled	Enable or disable Memory Remap above 4G.
Memory Alias Check	Enabled Disabled	Enable or disable Memory Alias Check.
Channel A DIMM Control	Enable Both DIMMS Disable DIMM0 Disable DIMM1 Disable Both DIMMS	Enable or disable dims on channel A.
Channel B DIMM Control	Enable Both DIMMS Disable DIMM0 Disable DIMM1 Disable Both DIMMS	Enable or disable dims on channel B.

Memory Thermal Configuration

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Chipset

Memory Thermal Configuration		Enable or disable Memory Thermal Management.
Memory Thermal Management	[Enabled]	

→← : Select Screen
↑↓ : Select Item
Enter: Select
+/- : Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

GT – Power Management Control

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Chipset

<p>GT – Power Management Control GT Info</p> <p>RC6 (Render Standby) RC6+(Deep RC6) GT Overclocking Support</p>	<p>GT1 (0x102)</p> <p>[Enabled] [Enabled] [Disabled]</p>	<p>Check to enable render standby support.</p>
		<p>→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</p>

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
RC6 (Render Standby)	Enabled Disabled	Check to enable render standby support.
RC6+(Deep RC6)	Enabled Disabled	Check to enable Deep RC6 (RC6+) support.
GT Overclocking Support	Enabled Disabled	Enable or disable GT Overclocking Support.

Function	Selection	Description
Setup Prompt Timeout	1, 2 - 65535 (Note)	Number of seconds to wait for setup activation key. 65535 (0xFFFF) means indefinite waiting.
Bootup NumLock State	On Off	Select the Keyboard Numlock state.
Quit Boot	Disabled Enabled	Enables or disables Quiet Boot option.
Fast Boot	Disabled Enabled	Enables or disables boot with initialization of a minimal set of devices required to launch active boot option. Has no effect for BBS boot options.
GateA20 Active	Upon Request Always	Upon Request: GA20 can be disabled using BIOS services. Always: do not allow disabling GA20; this option is useful when any RT code is executed above 1MB.
Option ROM Message	Force BIOS Keep Current	Set display mode for Option ROM.
INT19 Trap Response	Immediate Postponed	BIOS reaction on INT19 trapping by Option ROM. Immediate: execute the trap right away. Postponed: execute the trap during legacy boot.
Boot Option #1	(list of bootable devices)	Sets the system boot order.

Note: To enter number use digit keys and/or +/- keys.

10.4.1 CSM16 parameters

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Boot

CSM16 Parameters		UPON REQUEST – GA20 can be disabled using BIOS services. ALWAYS – do not allow disabling GA20; this option is useful when any RT code is executed above 1MB.
CSM16 Module Version	07.70	
GateA20 Active	[Upon Request]	
Option ROM Message	[Force BIOS]	
INT19 Trap Response	[Immediate]	
		→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
GateA20 Active	Upon Request Always	Upon Request: GA20 can be disabled using BIOS services. Always: do not allow disabling GA20; this option is useful when any RT code is executed above 1MB.
Option ROM Message	Force BIOS Keep Current	Set display mode for Option ROM.
INT19 Trap Response	Immediate Postponed	BIOS reaction on INT19 trapping by Option ROM: Immediate: execute the trap right away. Postponed: execute the trap during legacy boot.

10.4.2 Force Boot Setup

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Boot

Force Boot Setup		This option controls if CSM will be launched.
Force Boot	[Enabled]	
1 st Boot	[Sata Port]	→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Port #	1	
2 nd Boot	[Device Name]	
Device Name	[ST3120827AS]	
3 rd Boot	[USB]	
4 th Boot	[N/A]	

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function		Selection	Description
Force Boot		Disabled Enabled	
1st Boot (2nd Boot) (3rd Boot) (4th Boot)	Note1	N/A USB SATA SATA Port Device Name	
Port #	Note2	0 - 5	Note4
Device Name	Note3	None ST3120827AS *N/A * *N/A * *N/A *	

Note 1: 1st Boot, 2nd Boot, 3rd Boot and 4th Boot have the same set of selections.

Note 2: Only shown if SATA Port is selected.

Note 3: Only shown if Device Name is selected.

Note 4: By +/- key select requested port number. Make sure only valid number (0 – 5) is selected.

10.4.3 CSM parameters

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Boot

Launch CSM	[Enabled]	This option controls if CSM will be launched.
Boot option filter	[UEFI and Legacy]	
Launch PXE OpROM policy	[Do not launch]	
Launch Storage OpROM policy	[Legacy only]	
Launch Video OpROM policy	[Legacy only]	
Other PCI device ROM priority	[UEFI OpROM]	

→← : Select Screen
 ↑↓ : Select Item
 Enter: Select
 +/- : Change Opt.
 F1: General Help
 F2: Previous Values
 F3: Optimized Defaults
 F4: Save & Exit
 ESC: Exit

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
Launch CSM	Enabled Disabled	This option controls if CSM will be launched.
Boot option filter	UEFI and Legacy Legacy only UEFI only	This option controls what devices system can boot to.
Launch PXE OpROM policy	Do not launch UEFI only Legacy only	Controls the execution of UEFI and Legacy PXE OpROM.
Launch Storage OpROM policy	Do not launch UEFI only Legacy only	Controls the execution of UEFI and Legacy Storage OpROM.
Launch Video OpROM policy	Do not launch UEFI only Legacy only	Controls the execution of UEFI and Legacy Video OpROM.
Other PCI device ROM priority	UEFI OpROM Legacy OpROM	For PCI devices other than Network, Mass storage or Video defines which OpROM to launch.

10.5 Security

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Main Advanced Chipset Boot **Security** Save & Exit

<p>Password Description</p> <p>If ONLY the Administrator's password is set, then this only limits access to Setup and is only asked for when entering Setup.</p> <p>If ONLY the User's password is set, then this is a power on password and must be entered to boot or enter Setup. In Setup the User will have Administrator rights.</p> <p>The password length must be in the following range:</p> <table style="width: 100%; border: none;"> <tr> <td style="padding-right: 20px;">Minimum length</td> <td style="text-align: center;">3</td> </tr> <tr> <td>Maximum length</td> <td style="text-align: center;">20</td> </tr> </table> <p>Administrator Password User Password</p> <p>HDD Security Configuration: P1:ST3120827AS</p>	Minimum length	3	Maximum length	20	<p style="text-align: center;">Set Administrator Password</p> <hr/> <p>→← : Select Screen ↑↓ : Select Item Enter: Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</p>
Minimum length	3				
Maximum length	20				

Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Function	Selection	Description
Administrator Password	(See Password description above)	Set Administrator Password
User Password	(See Password description above)	Set User Password

10.5.1 HDD Security Configuration

Aptio Setup Utility – Copyright © 2012 American Megatrends, Inc.

Security

<p>HDD Password Description :</p> <p>Allows Access to set, Modify and Clear HardDisk User and Master Passwords. User Password need to be installed for Enabling Security. Master Password can be modified only when successfully unlocked with Master Password in POST.</p> <p>HDD PASSWORD CONFIGURATION:</p> <p>Security Supported : Yes</p> <p>Security Enabled : No</p> <p>Security Locked : No</p> <p>Security Frozen : No</p> <p>HDD User Pwd Status : NOT INSTALLED</p> <p>HDD Master Pwd Status : INSTALLED</p> <p>Set User Password</p>	<p>Set HDD User Password. *** Advisable to Power Cycle System after Setting Hard Disk Passwords ***</p>
	<p>→← : Select Screen</p> <p>↑↓ : Select Item</p> <p>Enter: Select</p> <p>+/- : Change Opt.</p> <p>F1: General Help</p> <p>F2: Previous Values</p> <p>F3: Optimized Defaults</p> <p>F4: Save & Exit</p> <p>ESC: Exit</p>


Version 2.15.1236. Copyright © 2012 American Megatrends, Inc

Only visible if entering a device listed below HDD Security Configuration.

Function	Selection	Description
Set User Password	Create New Password	Set HDD User Password. *** Advisable to Power Cycle System after Setting Hard Disk Passwords ***

10.6 Save & Exit

This Menu is special; having no “selections” for each function, or in other words, the function is the same as the selection.



Function	Description
Save Changes and Exit	Exit system setup after saving the changes.
Discard Changes and Exit	Exit system setup without saving any changes.
Save Changes and Reset	Reset the system after saving the changes.
Discard Changes and Reset	Reset the system without saving any changes.
Save Changes	Save Changes done so far to any of the setup options.
Discard Changes	Discard Changes done so far to any of the setup options.
Restore Defaults	Restore/Load Default values for all the setup options.
Save as User Defaults	Save the Changes done so far as User Defaults.
Restore User Defaults	Restore the User Defaults to all the setup options.
(possible list of boot devices)	Selection table of bootable devices. When selected system will boot on selected device. (See note below)
Launch EFI Shell From filesystem device	Attempts to Launch EFI Shell application (Shellx64.efi) from one of the available filesystem devices.

Note: When pressing <F7> while booting it is possible manually to select boot device.

11 AMI BIOS Beep Codes

It is normal for Kontron AMI UEFI BIOS to generate some beeps after POST has passed successfully:

The first beep indicates that POST has successfully passed.

Then a number of beeps indicate the number of attached USB devices.

And finally a special long beep indicates that AMI boot is completed.

Note: The long beep starting as a normal beep but is changing to higher frequency.

If POST has found a problem, then the normal behaviour (described above) is changed:

Boot Block Beep Codes:

Number of Beeps	Description
1	Insert diskette in floppy drive A:
2	'AMIBOOT.ROM' file not found in root directory of diskette in A:
3	Base Memory error
4	Flash Programming successful
5	Floppy read error
6	Keyboard controller BAT command failed
7	No Flash EPROM detected
8	Floppy controller failure
9	Boot Block BIOS checksum error
10	Flash Erase error
11	Flash Program error
12	'AMIBOOT.ROM' file size error
13	BIOS ROM image mismatch (file layout does not match image present in flash device)

POST BIOS Beep Codes:

Number of Beeps	Description
1	Memory refresh timer error.
2	Parity error in base memory (first 64KB block)
3	Base memory read/write test error
4	Motherboard timer not operational
5	Processor error
6	8042 Gate A20 test error (cannot switch to protected mode)
7	General exception error (processor exception interrupt error)
8	Display memory error (system video adapter)
9	AMIBIOS ROM checksum error
10	CMOS shutdown register read/write error
11	Cache memory test failed

Troubleshooting POST BIOS Beep Codes:

Number of Beeps	Troubleshooting Action
1, 2 or 3	Reset the memory, or replace with known good modules.
4-7, 9-11	Fatal error indicating a serious problem with the system. Consult your system manufacturer. Before declaring the motherboard beyond "all hope", eliminate the possibility of interference due to a malfunctioning add-in card. Remove all expansion cards, except the video adapter. <ul style="list-style-type: none"> • If beep codes are generated when all other expansion cards are absent, consult your system manufacturer's technical support. • If beep codes are not generated when all other expansion cards are absent, one of the add-in cards is causing the malfunction. Insert the cards back into the system one at a time until the problem happens again. This will reveal the malfunctioning card.
8	If the system video adapter is an add-in card, replace or reset the video adapter. If the video adapter is an integrated part of the system board, the board may be faulty.

12 OS Setup

Use the Setup.exe files for all relevant drivers. The drivers can be found on KTQ67 Driver CD or they can be downloaded from the homepage <http://www.kontron.com/>